

ENGINES, GASOLINE

GROUP

21
(6000 & 9000)

SECTION TITLE	PAGE	SECTION TITLE	PAGE
ENGINE, GASOLINE—SERVICE.....	21-01-1	ENGINE, 1.6L	21-10-1

SECTION 21-01 Engine, Gasoline—Service

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION		DIAGNOSIS AND TESTING (Cont'd.)	
Emission Calibration Label.....	21-01-2	Engine Oil Leaks	21-01-2
Engine Identification	21-01-2	Positive Closed-Type Crankcase Ventilation System.....	21-01-2
Exhaust Emission Control System.....	21-01-2	Static Engine Off Valve Train Analysis	21-01-4
DIAGNOSIS AND TESTING		SPECIAL SERVICE TOOLS	21-01-5
Camshaft Lobe Lift	21-01-4	VEHICLE APPLICATION	21-01-1
Compression Test	21-01-3		
Dynamic Valve Train Analysis.....	21-01-4		

VEHICLE APPLICATION

Capri.

DESCRIPTION

This Section covers various engine tests and cleaning and inspection procedures.

For engine removal, disassembly, cleaning and inspection, assembly, installation, adjustment procedures and specifications, refer to Section 21-10.

These engines incorporate a closed-type crankcase ventilation system and exhaust emission control system. All engine / emission control systems are covered in Engine / Emissions.

To maintain the required exhaust emission levels, the fuel system, ignition system and engine must be kept in good operating condition and meet recommended adjustment specifications.

When performing tests, adjustment or service to the engine or fuel / ignition system, it is essential to follow the procedures and specifications in the appropriate group in this manual.

Before replacing damaged or worn engine components such as the crankshaft, cylinder heads, valve guides, valves, camshafts or cylinder block, make sure that part(s) is not serviceable.

WARNING: TO AVOID THE POSSIBILITY OF PERSONAL INJURY OR DAMAGE TO THE VEHICLE, DO NOT OPERATE THE ENGINE WITH THE HOOD OPEN UNTIL THE FAN HAS FIRST BEEN EXAMINED FOR POSSIBLE CRACKS AND SEPARATION.

DESCRIPTION (Continued)**Exhaust Emission Control System**

Operation, removal, installation and required maintenance of the exhaust emission control devices used on these engines are covered in Engine/Emissions.

Engine Identification

For quick engine identification, refer to the Safety Certification Decal. The decal is mounted on the LH front door lock face panel. Find the engine code (letter or number) on the decal, then refer to the engine identification chart to determine the engine type and size. An engine identification label is also attached to the engine. The symbol code on the identification tag identifies each engine for determining parts usage; for instance, engine displacement and model year. Engine decal information is located in the appropriate engine section.

Emission Calibration Label

The emission calibration number label is located on the LH side door or LH door post pillar. It identifies the engine calibration number, the engine code number and revision level.

These numbers are used to determine if parts are unique to specific engines.

Always refer to these labels when replacement parts are required or when checking engine calibrations. Engine parts often differ within a CID family. Verification of identification codes will ensure that the proper parts are obtained. The codes contain all pertinent information relating to dates, optional equipment and revisions. The Ford Master Parts Catalog contains a complete listing of the codes and their application.

DIAGNOSIS AND TESTING**Positive Closed-Type Crankcase Ventilation System**

A malfunctioning closed crankcase ventilation system may be indicated by loping or rough engine idle. Do not attempt to compensate for this idle condition by disconnecting the crankcase ventilation system and making an air by-pass or idle speed adjustment.


CAUTION: The removal of the crankcase ventilation system from the engine will adversely affect the fuel economy and engine ventilation with resultant shortening of engine life.

To determine whether the loping or rough idle condition is caused by a malfunctioning crankcase ventilation system, refer to Engine/Emissions.

Engine Oil Leaks

When diagnosing engine oil leaks, it is important that the source and location of the leak be positively identified prior to service. The following procedure has been found to be very effective and requires only a minimum of equipment. Prior to using this procedure, it is important to clean the cylinder block, cylinder head, cylinder head cover, oil pan and flywheel housing areas with a suitable solvent to remove all traces of oil.

Use the following procedure to perform oil leak diagnosis with Rotunda Oil Leak Detector 112-00021 or equivalent.



AM298-A

Fluorescent Oil Additive Method

1. Clean engine with a suitable solvent to remove all traces of oil.
2. Drain engine oil crankcase and refill with recommended oil, premixed with Fluorescent Oil Additive ESE-M99C103-A or equivalent. Use a minimum 14.8ml (1/2 fluid ounce) to a maximum 29.6ml (1 fluid ounce) of fluorescent additive to all engines. If oil is not premixed, fluorescent additive must be added to crankcase first.
3. Run engine for 15 minutes. Stop engine and inspect all seal and gasket areas for leaks using Rotunda Oil Leak Detector 112-00021 or equivalent. A clear bright yellow or orange area will identify leak.
4. If necessary, pressurize main oil gallery system to locate leaks due to improperly sealed, loose or cocked plugs. If flywheel bolts leak oil, look for sealer on threads.
5. Service all leaks as required.

Pressure Method**Alternative Testing Procedure**

The main oil gallery can be pressurized to locate oil leaks. The following materials are required to fabricate the tool to be used.

1. Air supply and air hose.
2. Air pressure gauge that registers pressure in one psi increments.
3. Air line shutoff valve.
4. Appropriate fittings to attach above parts to oil fill and PCV tube connections.

DIAGNOSIS AND TESTING (Continued)

5. Appropriate plugs to seal any openings leading to crankcase.
6. A solution of liquid detergent and water to be applied with a suitable-type applicator such as a squirt bottle or brush.

Fabricate the air supply hose to include the air line shutoff valve and the appropriate adapter to permit the air to enter the engine through the cylinder head cover tube. Fabricate the air pressure gauge to a suitable adapter for installation on the engine at the oil fill opening.

Testing Procedure

1. Open air supply valve until pressure gauge maintains 34 kPa (5 psi).
2. Inspect sealed and/or gasketed areas for leaks by applying Snoop Pressure Check or a solution of liquid detergent and water over areas for formation of bubbles, which indicates leakage.

Possible Leakage Points

Examine the following areas for oil leakage.

Under Hood

- Cylinder head cover gasket.
- Intake manifold gasket.
- Cylinder head gasket.
- Oil filter.
- Distributor O-ring.
- Oil level indicator (dipstick) tube connection.
- Oil pressure sending unit.
- Cup plugs and/or pipe plugs at end of oil passages.

Under Engine--With Vehicle on Hoist

- Oil pan gasket.
- Oil pan front and rear end seals.
- Crankshaft front seal.
- Crankshaft rear seal.

With Transmission and Flywheel Removed

- Crankshaft rear seal.
- Rear main bearing cap parting line.

- Rear main bearing cap and seals.
- Flywheel mounting bolt holes.
- Rear cup plugs and or pipe plugs at the end of oil passages.

Air leakage in area around a crankshaft rear oil seal does not necessarily indicate a rear seal leak. However, if no other cause can be found for oil leakage, it can be assumed that rear seal is the cause of the oil leakage.

Oil leaks at crimped seams in sheet metal parts and cracks in cast or stamped parts can be detected when pressurizing the crankcase.

NOTE: Light foaming equally around cylinder head cover bolts and crankshaft seals is normal and no corrections are required in such cases.

Compression Test**Compression Gauge Check**

1. Ensure oil in crankcase is of the correct viscosity and at proper level and battery is properly charged. Operate vehicle until engine is at normal operating temperature. Turn off ignition switch, then remove all spark plugs.
2. Set throttle plate to wide-open position.
3. Install a compression gauge such as Rotunda Compression Tester 059-00009 or equivalent in No. 1 cylinder.
4. Install an auxiliary starter switch in starting circuit. With ignition switch in the OFF position, and using auxiliary starter switch, crank engine at least five compression strokes and record highest reading. Note the approximate number of compression strokes required to obtain the highest reading.
5. Repeat test on each cylinder, cranking the engine approximately the same number of compression strokes.

Test Conclusion

The indicated compression pressures are considered within specification if the lowest reading cylinder is within 75 percent of the highest. Refer to the Compression Pressure Limit Chart.

DIAGNOSIS AND TESTING (Continued)

Maximum PSI	Minimum PSI	Maximum PSI	Minimum PSI	Maximum PSI	Minimum PSI	Maximum PSI	Minimum PSI
134	101	164	123	194	145	224	168
136	102	166	124	196	147	226	169
138	104	168	126	198	148	228	171
140	105	170	127	200	150	230	172
142	107	172	129	202	151	232	174
144	108	174	131	204	153	234	175
146	110	176	132	206	154	236	177
148	111	178	133	208	156	238	178
150	113	180	135	210	157	240	180
152	114	182	136	212	158	242	181
154	115	184	138	214	160	244	183
156	117	186	140	216	162	246	184
158	118	188	141	218	163	248	186
160	120	190	142	220	165	250	187
162	121	192	144	222	166		

CA14297-A

If one or more cylinders read low, squirt approximately one tablespoon of heavy SAE 50 weight or equivalent engine oil on top of the pistons in the low reading cylinders. Repeat compression pressure check on these cylinders.

1. If compression improves considerably, piston rings are at fault.
2. If compression does not improve, valves are sticking or seating improperly.
3. If two adjacent cylinders indicate low compression pressures and squirting oil on pistons does not increase compression, cause may be a cylinder head gasket leak between cylinders. Engine oil and/or coolant in cylinders could result from this problem.

It is recommended the Compression Pressure Limit Chart be used when checking cylinder compression so that the lowest reading number is 75 percent of the highest reading.

Example

If, after checking the compression pressures in all cylinders, it was found that the highest reading obtained was 196 psi and the lowest pressure reading was 155 psi, the engine is within specification and the compression is considered satisfactory.

Static Engine Off Valve Train Analysis**Cylinder Head Cover Removed**

NOTE: Refer to Section 21-10 for the Removal and Installation of the engine cylinder head cover.

Static checks (engine off) are to be made on the engine prior to the dynamic procedure.

Check for damaged and/or severely worn parts, for correct assembly, and ensure use of correct parts by proceeding as follows, with the static engine analysis.

Cylinder Head

- Check the cylinder head gasket for proper installation.
- Check for plugged oil drain back holes.
- Check valve lash. Refer to Section 21-10.

Dynamic Valve Train Analysis

Start the engine and, while running at idle, check for proper operation of all parts. Check the following:

Cylinder Head

- Check for plugged oil drain back holes.

Camshaft Lobe Lift

Check the lift of each lobe in consecutive order and make a note of the readings.


1. Remove cylinder head cover.

DIAGNOSIS AND TESTING (Continued)

2. Install Dial Indicator TOOL-4201-C or equivalent in such a manner as to have dial indicator tip on the crankshaft lobe being checked.
3. Remove spark plugs.
4. Connect an auxiliary starter switch in starting circuit. Crank engine with ignition switch in OFF position. "Bump" engine over until dial indicator tip is on base circle of camshaft lobe. At this point, dial indicator will be in its lowest position. If checking during engine assembly, turn crankshaft using a socket or ratchet.

5. Zero dial indicator. Continue to rotate crankshaft slowly until camshaft lobe is at full lift position (highest indicator reading).

NOTE: Camshaft lobe lift must be checked at two points as illustrated.



6. Compare total lift recorded on indicator with specifications.
7. To check accuracy of original indicator reading, continue to rotate crankshaft until indicator reads zero.
NOTE: If lift on any lobe is below specified service limits, camshaft must be replaced.
8. Remove dial indicator and auxiliary starter switch.
9. Install cylinder head cover.
10. Install spark plugs.

SPECIAL SERVICE TOOLS

Tool Number	Description
TOOL-4201-C	Dial Indicator with Bracketry

ROTUNDA EQUIPMENT

Model	Description
112-00021	Oil Leak Detector
059-00009	Compression Tester

SECTION 21-10 Engine, 1.6L

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	21-10-1	REMOVAL AND INSTALLATION (Cont'd.)	
DISASSEMBLY AND ASSEMBLY		Throttle Body	21-10-19
Assembly	21-10-33	Timing Belt	21-10-12
Flywheel, Pilot Bearing	21-10-34	Valve Stem Seals	21-10-19
Oil Pump	21-10-33	Water Pump	21-10-17
Cylinder Head	21-10-30	SERVICE PROCEDURES	
Engine	21-10-24	Camshaft	21-10-45
Subassemblies	21-10-32	Connecting Rod	21-10-39
Piston and Connecting Rod	21-10-32	Crankshaft	21-10-39
REMOVAL AND INSTALLATION		Crankshaft and Connecting Rod	
Camshaft	21-10-14	Bearings	21-10-40
Camshaft Seal	21-10-17	Crankshaft End Play	21-10-40
Camshaft Seals	21-10-22	Crankshaft Oil Clearance	21-10-40
Core Plugs	21-10-23	Cylinder Block	21-10-34
Crankshaft Oil Seal, Front	21-10-23	Cylinder Block Flatness	21-10-35
Crankshaft Oil Seal, Rear	21-10-23	Cylinder Bores	21-10-36
Crankshaft, Main Bearings and Connecting		Cylinder Head	21-10-42
Rod Bearings	21-10-16	Cylinder Head Flatness	21-10-42
Cylinder Head	21-10-10	Valve and Valve Guide	21-10-43
Engine Assembly	21-10-2	Valve Seat	21-10-44
Engine Mount, Front	21-10-9	Valve Spring	21-10-44
Engine Mount, Rear	21-10-9	Oil Jet	21-10-42
Engine Mount, RH	21-10-9	Oil Pump	21-10-41
Exhaust Manifold	21-10-18	Pistons, Piston Rings and Piston Pins	21-10-37
Intake Manifold	21-10-17	Service Limit Specifications	21-10-34
Oil Pan	21-10-19	SPECIAL SERVICE TOOLS	21-10-49
Oil Pump	21-10-20	SPECIFICATIONS	21-10-47
Piston and Connecting Rod Assembly	21-10-21	VEHICLE APPLICATION	21-10-1
Thermostat	21-10-19		

VEHICLE APPLICATION

Capri.

DESCRIPTION

The 1.6L naturally aspirated and 1.6L Turbocharged / Intercooled engines are double overhead cam (DOHC), four valves per cylinder, four cylinder engines. The cylinder head is aluminum and incorporates directly operating bucket-type hydraulic lash adjusters (HLA).

The camshafts are driven by the crankshaft by a single, toothed belt. One camshaft operates the intake valves, one operates the exhaust valves. The timing belt is automatically adjusted by a spring tensioned pulley.


The intake manifold is aluminum and has a coolant passage for better driveability during cold weather operation.

The ignition system is an electronic, high output type utilizing a vacuum operated advance distributor. The distributor is driven directly off the intake camshaft.

The fuel injection system is electronic. A vane air flow meter (VAF) senses intake air flow rate and temperature. An electric fuel pump, mounted inside the fuel tank delivers fuel at a constant rate to the fuel pressure regulator. The pressure regulator returns excess fuel to the fuel tank while keeping the four fuel injectors supplied with sufficient fuel through the fuel rail assembly.

Injector "on time" is controlled by the electronic control unit (ECU), based on information supplied by the VAF, coolant temperature sensor, and throttle position sensor (TPS).


The lubrication system is a high pressure-type supplied by the oil pump. The oil pump is driven directly by the crankshaft. On turbocharged engines, oil spray nozzles are mounted in the cylinder block and spray oil up into the pistons to aid in cooling and prevent detonation.

DESCRIPTION (Continued)

A13501-A

REMOVAL AND INSTALLATION**Engine Assembly****Removal**



1. Relieve fuel pressure by disconnecting electrical connector at fuel pump-sending unit assembly located under rear seat cushion. If necessary, refer to Section 41-20 for rear seat cushion removal.
2. Start the engine and allow it to run until it stalls. The fuel pressure is now relieved.
3. Discharge the air conditioning system, if equipped. Refer to Section 36-32.
4. Disconnect and remove battery, battery tray and battery tray support bracket.



A13142-A

REMOVAL AND INSTALLATION (Continued)


5. Release wiring harness retaining straps from battery support tray.
6. Disconnect windshield washer supply hose between washer fluid reservoir and hood.
7. Mark hood hinge locations and remove hood.
8. Disconnect intake air tube and wiring to ignition coil and vane air flow meter.
9. Remove air cleaner / vane air flow meter assembly.
10. Remove air cleaner assembly support brackets. Refer to Section 24-41.
11. Disconnect intercooler hoses from turbocharger, if equipped.
12. Drain engine coolant and remove radiator. Refer to Section 27-01 and 27-03.
13. Disconnect accelerator cable and remove retaining bracket from cylinder head cover. Position cable aside. Refer to Section 24-60.



A12947-A


14. Disconnect speedometer cable at cable connection located under hood. Refer to Section 33-10.

15. Disconnect and plug fuel lines at fuel filter and pressure regulator.
16. Disconnect power brake booster manifold vacuum hose from manifold.
17. Disconnect heater hoses at heater core tubes.



A13146-A

18. Label and remove vacuum hoses located at throttle body.




1.6L TURBOCHARGED SHOWN
1.6L NATURALLY ASPIRATED TYPICAL


A12927-A

REMOVAL AND INSTALLATION (Continued)

19. For manual transaxle turbocharged vehicles, disconnect clutch cable and remove support bracket and cable from transmission. On naturally aspirated vehicles, disconnect clutch slave cylinder hydraulic line. Refer to Section 16-37.




A12948-A



C9657-A

20. For automatic transaxle, remove transaxle cooler lines.




A13143-A

21. Disconnect starter wiring at starter. Remove harness from locating strap on bracket.
22. Disconnect alternator wiring.
23. Disconnect wiring from engine coolant sensors located on rear of engine block.
24. Remove ground connection at bracket on thermostat cover.
25. Disconnect EGO sensor wire, main wiring harness connector, TPS connector (turbocharged vehicles only), knock sensor connector, distributor wiring and transaxle wiring.
26. Disconnect ground wire and strap at front of engine. Reinstall lifting eye.
27. Remove engine oil dipstick and dipstick retaining clip.
28. Remove power steering pump from bracket. Refer to Section 13-51.
29. Remove power steering pump mounting bracket.
30. Position power steering pump aside (hoses attached).
31. Remove upper air conditioning compressor retaining bolts, if equipped.
32. Raise vehicle on hoist. Refer to Section 10-04.
33. Drain engine oil. Drain cooling system. Refer to Section 27-01.
34. On vehicles with air conditioning, remove lower air conditioning compressor mounting bolts and position compressor out of the way.
CAUTION: Do not let compressor hang by the hoses. Tie up with mechanic's wire.
35. Remove front wheel and tire assemblies. Refer to Section 11-01.
36. Remove front ball joints to steering knuckles retaining bolts. Refer to Section 14-01.
37. Remove splash guards.
38. Drain transmission oil and remove halfshafts from differential. Refer to Section 15-22.
39. Remove front exhaust pipe bracket located on lower side of engine.
40. Disconnect front exhaust pipe from exhaust manifold, or turbocharger, if so equipped.
41. Remove frame support bar to engine support bolt. Loosen right control arm bolt and pivot support bar downward.
42. Disengage rubber exhaust hangers located directly behind catalytic converter.
43. Allow exhaust system to hang down six inches and support with mechanic's wire.

REMOVAL AND INSTALLATION (Continued)



44. Unbolt transaxle shift linkage and stabilizer bar at transaxle.



A12946-A

45. Remove nuts from front and rear engine mounts.
46. Lower vehicle.

REMOVAL AND INSTALLATION (Continued)




47. Position Rotunda Engine Lifting Crane 077-00043 or equivalent. Attach chains onto lift eyes located on sides of cylinder head.
48. Support engine with lift and remove RH engine mount through-bolt.
49. Raise engine off of mounts and slightly pivot engine/transaxle assembly.
50. Disconnect oil pressure sensor and route starter/alternator wiring harness from engine.
51. Carefully lift engine/transaxle assembly, turn assembly while raising to clear the brake master cylinder, shift linkage universal joint, radiator support and air conditioning lines, if so equipped.
52. Remove intake manifold support bracket.

REMOVAL AND INSTALLATION (Continued)

53. Remove gusset plate(s), if equipped.
54. Remove starter.
55. Remove transaxle to engine retaining bolts. Identify bolts to ensure they are installed in their correct locations for installation.
56. Separate transaxle from engine.
57. On manual transaxles, remove pressure plate, clutch disc, and flywheel.
58. On automatic transaxles, remove flywheel.


Installation

1. Remove engine from stand.
2. Install end plate. Tighten retaining screw to 8-11 N·m (69-95 lb-in).
3. For manual transaxle, install the following:
 - a. Install flywheel. Apply Thread Sealer EOAZ-19554-AA or equivalent to flywheel bolts. Tighten retaining bolts to 96-103 N·m (71-76 lb-ft).
 - b. Position clutch disc using Clutch Aligner T74P-7137-K or equivalent.
 - c. Install pressure plate. Tighten retaining bolts to 18-26 N·m (13-19 lb-ft).
4. For automatic transaxle, install flywheel. Tighten retaining bolts to 96-103 N·m (71-76 lb-ft).
5. Install intermediate axle shaft and bearing, if equipped. Tighten bearing mount retaining bolts to 37-52 N·m (27-38 lb-ft).
6. For manual transaxle, install as follows:
 - a. Position transaxle to engine and install retaining bolts.
 - b. Tighten bolts "A" to 89-117 N·m (66-86 lb-ft).
 - c. Tighten bolts "B" to 37-52 N·m (27-38 lb-ft).
7. For automatic transaxle, install as follows:
 - a. Position transaxle to engine and install retaining bolts.
 - b. Tighten bolts "A" to 55-80 N·m (41-59 lb-ft).
 - c. Align torque converter and flywheel. Install retaining bolts, tighten to 34-49 N·m (25-36 lb-ft).
 - d. Install cover plate. Tighten retaining bolts "B", to 7-10 N·m (61-87 lb-in).
 - e. Install gusset plate(s), if removed. Tighten retaining bolts on engine to 37-52 N·m (27-38 lb-ft). Tighten bolts to transaxle to 55-80 N·m (41-59 lb-ft).



A13147-A

8. Install starter. Tighten retaining bolts to 31-46 N·m (23-34 lb-ft).
9. Install intake manifold support bracket. Loosely install all bolts first. Tighten upper bolts to 31-46 N·m (22-34 lb-ft). Tighten lower bolts to 31-46 N·m (22-34 lb-ft).
10. Install starter bracket to manifold support bolt. Tighten to 19-25 N·m (14-19 lb-ft).




A13148-A

11. On turbocharged engines, install turbocharger inlet tube.
12. Using Rotunda Engine Lifting Crane 077-00043 or equivalent, lower engine and transmission assembly into vehicle. Before engine contacts engine mounts, route starter, alternator and oil pressure sensor wiring and connect oil pressure sensor.
13. Lower engine until front mount seats on crossmember. Install through bolt on RH engine mount. Do not tighten.
14. Remove lifting crane.
15. Raise vehicle with a hoist. Refer to Section 10-04.

REMOVAL AND INSTALLATION (Continued)

16. Align rear engine mount to crossmember and install retaining nuts to front and rear engine mounts. Tighten to 64-89 N·m (47-66 lb-ft).



17. On manual transaxles, connect shift coupling and stabilizer. Tighten linkage retaining nut to 16-22 N·m (12-17 lb-ft). Tighten stabilizer to 31-46 N·m (23-34 lb-ft).
18. On automatic transaxles, connect shift linkage and oil cooler lines. Tighten linkage retaining bolt to 8-11 N·m (69-95 lb-in). Tighten shift cable pivot nut to 44-64 N·m (33-47 lb-ft). Tighten oil cooler hose clamps.
19. Connect front exhaust pipe to manifold (or turbocharger).
20. Install exhaust pipe to support bracket. Tighten retaining bolts to 43-61 N·m (32-45 lb-ft).
21. Tighten manifold (or turbocharger) nuts to 39-57 N·m (29-42 lb-ft).
22. Attach rubber exhaust hangers.
23. Position cross brace. Tighten retaining nut and bolt to 35-50 N·m (26-37 lb-ft). Tighten right A-arm front bolt to 64-89 N·m (47-66 lb-ft).
24. Install drive axles to transaxle.
25. Install ball joint retaining bolts. Tighten to 43-54 N·m (32-40 lb-ft).
26. Mount A/C compressor to engine, if required. Tighten lower retaining bolts to 39-54 N·m (30-40 lb-ft).
27. Install splash guards.
28. Install tire and wheel assemblies. Tighten retaining nuts to 90-120 N·m (65-88 lb-ft).
29. Lower vehicle. Install upper A/C compressor retaining bolts, if required. Tighten to 39-54 N·m (30-40 lb-ft).
30. Tighten RH engine mount through bolt to 45-65 N·m (33-48 lb-ft).

31. Connect alternator wiring.


32. Position power steering pump bracket on stud. Lower power steering into engine compartment.
33. Install power steering pump bracket retaining bolts and nut. Tighten to 47-66 N·m (35-48 lb-ft).
34. Install power steering pump and belt. Tighten adjustment nut to 37-52 N·m (27-38 lb-ft). Tighten pivot bolt to 31-46 N·m (23-34 lb-ft).
35. Install engine oil dipstick and dipstick retaining clip.
36. Install ground strap and ground wire to cylinder head.
37. Install clutch cable, if manual transaxle/turbocharged. Connect clutch hydraulic line if manual transaxle/naturally aspirated. Refer to Section 16-02.
38. Connect transmission electrical connectors.
39. Connect engine electrical connectors.
40. Connect fuel lines to fuel filter and pressure regulator.
41. Install intake air tube to throttle body.
42. Install intercooler hoses, if turbocharged.
43. Install air cleaner assembly brackets.
44. Install air cleaner assembly, with VAF attached. Refer to Section 24-41.
45. Install intake air tube.
46. Connect coil and VAF connectors.
47. Connect coolant crankcase and air bypass hoses. Install vacuum hoses in correct locations as noted in disassembly.
48. Connect accelerator cable. Install retaining bracket.
49. Install power brake booster hose.
50. Remove speedometer cable from transaxle. Fill transaxle to specification. Refer to Section 16-37, 16-38 or 17-01.
51. Install speedometer cable. Connect speedometer cable connector.
52. Fill engine oil to specification. Refer to Section 10-03.
53. Install radiator/fan assembly. Tighten bracket retaining bolts to 8-11 N·m (69-95 lb-in). Connect coolant hoses and fan electrical connector.
54. Fill coolant to specification. Refer to Section 27-01.
55. Install hood. Tighten retaining bolts to 20-28 N·m (14-21 lb-ft). Connect washer hose.
56. Install battery tray support. Install battery tray, battery and battery hold down. Connect battery terminals. Refer to Section 31-02.
57. Evacuate and recharge air conditioning system, if required. Refer to Section 36-32.

REMOVAL AND INSTALLATION (Continued)

58. Start engine. Check for proper operation.
59. Road test vehicle. Check clutch and transmission for proper operation.

Engine Mount, RH**Removal**

1. Support engine assembly with floor jack.
2. Remove mount to engine bracket retaining nuts.
3. Remove through bolt.
4. Remove bracket to body retaining bolts.


**Installation**

1. Position bracket to body. Tighten smaller bolts to 20-28 N·m (14-21 lb-ft). Tighten larger bolt to 67-91 N·m (49-67 lb-ft).
2. Install engine mount to engine bracket. Tighten nuts to 60-85 N·m (44-63 lb-ft).
3. Install through bolt. Tighten to 45-65 N·m (33-48 lb-ft).
4. Remove floor jack.

Engine Mount, Front**Removal**

1. Support engine with Engine Support Fixture D88L-6000-A or equivalent.
2. Raise vehicle. Refer to Section 10-04.

3. Remove engine mount retaining nuts from crossmember.
4. Remove engine mount retaining bolts from transmission.
5. Remove through bolt, if required.


**Installation**

1. Position engine mount to transmission. Install retaining bolts. Tighten to 37-52 N·m (27-38 lb-ft).
2. Install engine mount to crossmember retaining nuts. Tighten to 64-89 N·m (47-65 lb-ft).
3. Install through bolt, if removed. Tighten to 45-65 N·m (33-47 lb-ft).
4. Lower vehicle.
5. Remove engine support fixture.

Engine Mount, Rear**Removal**

1. Support engine with Engine Support Fixture D88L-6000-A or equivalent.
2. Raise vehicle. Refer to Section 10-04.
3. Remove front and rear engine mount to crossmember retaining nuts. Remove crossmember brace retaining bolts.
4. Remove LH A-arm retaining bolt. Remove engine support crossmember retaining nuts and bolts.
5. Remove rear engine mount retaining bolts.

REMOVAL AND INSTALLATION (Continued)

**Installation**

1. Install rear engine mount. Tighten retaining bolts to 37-52 N·m (27-38 lb-ft).
2. Install crossmember. Tighten retaining bolts to 64-89 N·m (47-66 lb-ft). Tighten rear engine retaining nut to 64-89 N·m (47-66 lb-ft).
3. Install crossmember brace retaining bolts.
4. Install LH A-arm retaining bolt. Tighten to 64-89 N·m (47-66 lb-ft).
5. Install front and rear engine mount to crossmember retaining nuts. Tighten to 64-89 N·m (47-66 lb-ft).
6. Lower vehicle.
7. Remove engine support fixture.


Cylinder Head**Removal**

1. Release fuel pressure. Refer to Section 24-50.
2. Drain cooling system. Refer to Section 27-01.
3. Disconnect negative battery terminal.
4. Remove intake air tube from throttle body. Disconnect air bypass hoses.
5. Remove spark plug wires and retainers.
6. Remove intake air tube from air cleaner assembly.

7. Disconnect coolant hose from thermostat cover. Disconnect vacuum hoses and coolant hoses from throttle body and intake manifold.
8. Disconnect throttle cable and remove retaining brackets and cable.
9. Disconnect fuel lines at fuel filter and pressure regulator.
10. Disconnect main harness connector.
11. Disconnect EGO sensor connector and remove ground connection retaining screw at bracket.
12. Disconnect intercooler tubes from turbocharger, if equipped.
13. Remove ground wire and strap retaining bolts at front sides of cylinder head.
14. Remove timing belt covers, and timing belt as outlined.
15. On turbocharged vehicles, remove exhaust manifold and turbocharger as an assembly. Refer to Section 24-45.
16. On 1.6L EFI vehicles, disconnect front exhaust pipe from exhaust manifold.
17. Remove intake manifold support upper retaining bolts.
18. Remove cylinder head cover.
19. Remove cylinder head and intake manifold as an assembly.
20. Separate intake manifold from cylinder head, if required.

REMOVAL AND INSTALLATION (Continued)


21. Remove exhaust manifold, if required (1.6L naturally aspirated engine).



A13154-A

Installation

1. Install exhaust manifold with new gaskets. Ensure use of two piece gasket. Heavy gasket installs first. Tighten retaining nuts to 39-57 N·m (29-42 lb-ft).
2. Install intake manifold to cylinder head, if removed. Use new gasket.
NOTE: Ensure coolant passage openings in gasket align with manifold and cylinder head.
3. Tighten retaining nuts and bolts to 19-25 N·m (14-19 lb-ft).




A13153-A

4. Clean head gasket surfaces on cylinder head and cylinder block. Position new head gasket on block.
5. Carefully set cylinder head on block.

REMOVAL AND INSTALLATION (Continued)

6. Tighten cylinder head retaining bolts in sequence shown. First to 20-34 N·m (14-25 lb-ft), then to 76-81 N·m (56-60 lb-ft).




7. Install intake manifold support upper retaining bolts. Tighten to 31-46 N·m (22-39 lb-ft).
8. Install timing belt and covers, as outlined.
9. Install cylinder head cover. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
10. Connect front exhaust pipe to exhaust manifold, on 1.6L naturally aspirated engine. Tighten retaining nuts to 31-46 N·m (23-34 lb-ft).
11. Install exhaust manifold and turbocharger assembly (on turbocharged engines). Refer to Section 24-45.
12. Install ground wire and strap to cylinder head with retaining bolts.
13. Connect intercooler tubes, if equipped.
14. Connect EGO sensor connector and install ground wires to bracket on cylinder head with retaining screw.
15. Connect main engine harness connector.
16. Connect fuel lines to fuel filter and pressure regulator.
17. Install throttle cable and retaining brackets.

18. Install coolant hoses and vacuum lines to intake manifold and throttle body.
19. Install coolant hose to thermostat cover.
20. Install intake air tube to air cleaner.
21. Install spark plug wires and retainers.
22. Install intake air tube to throttle body. Connect air bypass hoses.
23. Fill cooling system. Refer to Section 27-01.
24. Connect negative battery terminal.
25. Start engine. Check for proper operation.

Timing Belt**Removal**

1. Raise vehicle on hoist. Refer to Section 10-04.
2. Remove right front tire and wheel assembly. Remove RH splash guard.
3. Lower vehicle.
4. Remove spark plugs. Set engine timing to TDC on No. 1 cylinder.
5. Remove alternator and power steering belts. Refer to Section 27-02.
6. Remove oil dipstick.
7. Remove water pump pulley.
8. Remove crankshaft pulley, damper and baffle plate.
9. Remove upper timing belt cover.
10. Remove center and lower timing belt covers.
11. Remove timing belt tension spring.
12. Loosen timing belt tension pulley.
13. Support engine with floor jack and remove RH engine mount as outlined.
NOTE: Mark timing belt rotation direction before removal.
14. Remove timing belt.


REMOVAL AND INSTALLATION (Continued)



Inspection

Timing Belt Tension Spring

When servicing the timing belt, check the free length of the timing belt tension spring. Replace if out of specification.




A13510-A

Timing Belt

CAUTION: Never twist, turn inside out, or bend timing belt. Keep belt away from grease and oil.

Replace the timing belt if affected by grease or oil. Check the timing belt for wear, tears, peeling, cracks or hardening. Replace the belt, if required.




A14291-A

Tensioner and Idler Pulleys

CAUTION: Do not clean tensioner or idler pulleys with solvents. Wipe them clean only.

Spin pulleys by hand and check for smooth rotation or abnormal noise. Replace, if required.



A14292-A

REMOVAL AND INSTALLATION (Continued)



Timing Belt Pulleys

CAUTION: Do not clean pulleys with solvents. Wipe them clean only.

Inspect pulleys for wear, deformation, or damage. Replace, if required.

Installation


1. Ensure timing marks are properly positioned on camshafts and crankshaft. The intake camshaft should have the letter "I" aligned with the arrow on the belt cover. The exhaust camshaft should have the letter "E" aligned with the arrow on the belt cover.
2. The crankshaft key should align with the arrow as shown.



A13182-A

3. Tighten tension pulley with tension spring fully extended.
4. Install timing belt. Keep tension on the opposite side of the tensioner as tight as possible. Ensure rotation mark on belt is correct.
5. Turn crankshaft two full turns. Check alignment marks. If any mark is not aligned, remove timing belt and reset timing.
6. Loosen tension pulley retaining bolt to allow tension spring to tighten belt.
7. Tighten tension pulley retaining bolt to 37-52 N·m (27-38 lb-ft). Rotate engine two full turns. Ensure timing marks are aligned.

8. Measure timing belt tension between camshaft pulleys. Belt deflection should be 8.5-11.5 mm (0.33-0.45 inch). If incorrect, loosen tension pulley and repeat procedure. If proper tension cannot be achieved, replace tension spring.



A13184-A

9. Install lower, center and upper timing belt covers. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
10. Install RH engine mount and lower engine. Tighten retaining nuts to 60-85 N·m (44-63 lb-ft).
11. Install crankshaft pulley, damper and baffle. Tighten baffle and damper retaining screws to 12-17 N·m (109-152 lb-in). Tighten pulley retaining bolts to 12-17 N·m (109-152 lb-in).
12. Install water pump pulley. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
13. Install alternator and power steering belts. Refer to Section 27-02.
14. Install oil dipstick.
15. Raise vehicle.
16. Install splash guard and right front wheel and tire assembly. Tighten lug nuts to 90-120 N·m (66-88 lb-ft).
17. Lower vehicle. Install spark plugs. Start engine. Check for proper operation.


Camshaft

Removal

1. Disconnect battery ground terminal.
2. Disconnect air bypass hoses and remove intake air tube.
3. Disconnect throttle cable and remove retaining brackets.
4. Remove cylinder head cover.
5. Remove timing belt, as outlined.


REMOVAL AND INSTALLATION (Continued)

6. Remove camshaft pulley(s). Hold camshaft with wrench to remove pulley retaining bolt.



A13156-A

7. Remove seal plate.
8. Remove camshaft seal using Seal Remover T78P-3504-N or equivalent.



A13157-A


9. Remove distributor, if removing intake camshaft.
10. Note numerical and directional markings on camshaft bearing caps for installation. Remove bearing cap retaining bolts alternately and gradually so as not to overstress camshaft.
11. Remove camshaft.

NOTE: For camshaft service, refer to Service Procedures in this Section.

Installation

1. Lubricate camshaft bearings with clean engine oil. Position camshaft in cylinder head. Ensure all tappets are in place. Install intake camshaft with the "I" straight up and exhaust camshaft with the "E" straight up.

2. Install bearing cap according to numbers and arrows. (Arrows to front of engine.) Tighten retaining bolts in sequence shown to 11-14 N·m (100-126 lb-in).




SEQUENCE SHOWN IS FOR INSTALLATION
OF BOTH CAMSHAFTS.
FOLLOW 1-10 SEQUENCE IF ONLY ONE CAM-
SHAFT IS BEING INSTALLED.


A13158-A

3. Install distributor, if removed.
4. Install camshaft seal using Seal Protector T90P-6256-AH and Seal Installer T90P-6256-BH or equivalent.

CAMSHAFT SEAL
INSTALLER
T90P-6256-BH



CAMSHAFT
SEAL
SEAL PROTECTOR
T90P-6256-AH



A13159-A

5. Install seal plate. Tighten retaining screws to 8-11 N·m (69-95 lb-in).
6. Install camshaft pulley. Tighten retaining bolt to 49-61 N·m (36-45 lb-ft).
7. Install timing belt, as outlined.


REMOVAL AND INSTALLATION (Continued)

8. Install cylinder head cover. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
9. Install throttle cable and retaining brackets.
10. Install intake air tube and connect air bypass hoses.
11. Connect battery ground terminal.
12. Start engine. Check for proper operation.

Crankshaft, Main Bearings and Connecting Rod Bearings

Removal

1. Remove timing belt, as outlined.
 2. Remove transaxle. Refer to Section 16-37, 16-38 or 17-27.
 3. Remove oil pan, as outlined.
 4. Remove oil pump, as outlined.
 5. Remove flywheel and clutch, if required.
 6. Remove rear crankshaft seal mounting flange.
 7. Remove connecting rod bearing caps. Note numerical and directional position for proper assembly.
 8. Loosen main bearing cap retaining bolts.
 9. With an assistant remove main bearing caps and crankshaft. Note position of bearing caps for proper assembly.
 10. Remove bearing inserts from connecting rods and rod caps, if required.
 11. Remove main bearing inserts and thrust bearings, if required.
- NOTE:** For crankshaft service, refer to Service Procedures in this Section.




A13160-A

REMOVAL AND INSTALLATION (Continued)**Installation**

1. Install upper connecting rod bearing inserts, if removed.
2. Install upper main bearing inserts, if removed.
3. Install lower main bearing inserts into main bearing caps.
4. With an assistant, install crankshaft using No. 2 bearing and cap.
5. Install thrust bearings.
6. Install remaining main bearings. Tighten retaining bolts to 54-59 N·m (40-43 lb-ft).
7. Install lower connecting rod bearing inserts, if removed. Install rod bearing caps. Tighten retaining nuts to 47-52 N·m (35-38 lb-ft).
8. Install rear crankshaft seal mounting flange. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
9. Install flywheel and clutch, if removed. Apply Thread Sealer EOAZ-19554-AA or equivalent to flywheel retaining bolts. Tighten bolts to 96-103 N·m (71-76 lb-ft).
10. Install oil pump, as outlined.
11. Install oil pan, as outlined.
12. Install transaxle, as outlined.
13. Install timing belt, as outlined.
14. Start engine. Check for leaks and proper operation.

Intake Manifold**Removal**

1. Disconnect negative battery terminal.
2. Relieve fuel system pressure. Refer to Engine/Emissions.
3. Drain cooling system. Refer to Section 27-01.
4. Disconnect intercooler tube and/or air intake tube. Disconnect air bypass hoses.
5. Disconnect main engine harness electrical connection and TPS connector.
6. Disconnect vacuum hoses from throttle body.
7. Disconnect fuel lines from fuel filter and pressure regulator.
8. Disconnect throttle cable.
9. Disconnect hoses from BAC valve.
10. Remove BAC valve retaining nut and bolt.
11. Remove intake manifold retaining bolts and nuts from support bracket and cylinder head.
12. Remove intake manifold and throttle body assembly.



A14286-A

Installation

1. Install new intake manifold gasket. Ensure coolant passage openings align with openings in cylinder head and manifold.
2. Install intake manifold. Tighten retaining nut and bolts to 19-25 N·m (14-19 lb-ft). Tighten support bracket retaining bolts to 31-46 N·m (23-34 lb-ft).
3. Install BAC valve, connect air hoses.
4. Connect throttle cable.
5. Connect fuel lines to fuel filters and pressure regulator.
6. Connect main engine harness connector and TPS connector.
7. Connect vacuum lines to throttle body.
8. Install intake air tube. Connect intercooler tube and/or air intake tube. Connect air bypass hoses.
9. Fill cooling system. Refer to Section 27-01.
10. Connect negative battery terminal.
11. Start engine. Check for proper operation.

Water Pump


Refer to Section 27-01.

Camshaft Seal**Removal**



1. Disconnect negative battery terminal.
2. Remove timing belt, as outlined.
3. Remove camshaft pulleys. Hold camshafts with wrench to remove pulley retaining bolt.
4. Remove seal plate.

REMOVAL AND INSTALLATION (Continued)

5. Remove camshaft seal using Seal Remover T78P-3504-N or equivalent.


**Installation**

1. Install camshaft seal using Seal Installer T90P-6256-BH and Camshaft Seal Protector T90P-6701-AH or equivalent.



2. Install seal plate. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).

3. Install camshaft pulleys. Install intake camshaft pulley with the "I" straight up, and the exhaust camshaft pulley with the "E" straight up. Tighten retaining bolt to 49-61 N·m (36-45 lb-ft). Hold camshaft with wrench while tightening retaining bolt.



4. Install timing belt, as outlined.
5. Connect negative battery terminal.
6. Start engine. Check for leaks and proper operation.

Exhaust Manifold**Naturally Aspirated Engine****Removal**

1. Remove intake air tube.
2. Remove front exhaust pipe to exhaust manifold retaining nuts.
3. Remove exhaust support bracket, if equipped.
4. Remove heat shield.
5. Disconnect EGO sensor electrical connector.
6. Remove exhaust manifold.

Installation

1. Install exhaust manifold gaskets. Heavier gasket installs first.
2. Install exhaust manifold. Tighten retaining nuts to 39-57 N·m (29-42 lb-ft).
3. Connect EGO sensor electrical connector.
4. Install manifold heat shield.
5. Install intake air tube.
6. Connect front exhaust pipe to intake manifold. Tighten retaining nuts to 31-46 N·m (23-34 lb-ft).
7. Install exhaust support bracket, if removed. Tighten engine mount bolt to 67-91 N·m (49-67 lb-ft).

REMOVAL AND INSTALLATION (Continued)

8. Start engine. Check for leaks.

Turbocharged Engine**Removal**

1. Remove exhaust manifold and turbocharger assembly. Refer to Section 24-45.
2. Separate exhaust manifold from turbocharger.

Installation

1. Install manifold to turbocharger assembly with new gasket. Tighten retaining nuts to 31-46 N·m (23-34 lb-ft).
2. Install exhaust manifold and turbocharger assembly. Refer to Section 24-45.

Throttle Body

Refer to Section 24-60.

Thermostat

Refer to Section 27-01.

Valve Stem Seals**Cylinder Head Installed****Removal and Installation**

1. Remove timing belt and camshafts, as outlined.
2. Remove spark plugs.
3. To replace valve stem seals:
 - a. Rotate crankshaft to bring piston to TDC.
 - b. Pressurize cylinder with air using Rotunda Air Pressurization Kit 014-00705 or equivalent.
 - c. Remove hydraulic valve adjuster.


- d. Remove valve spring and keepers using Valve Spring Compressor T90P-6565-A, Pivot Bar T87C-6565-A and Valve Spring Compressor Brackets T89P-6565-AH or equivalent.
 - e. Remove valve stem seal using Valve Stem Seal Remover T89P-6510-D or equivalent.
 - f. Lubricate new valve stem seal. Install seal using Valve Stem Seal Replacer T90P-6510-AH or equivalent.
4. Repeat procedure for each cylinder. Keep air charge in each cylinder until all valve springs in that cylinder are securely installed.
 5. Install spark plugs.
 6. Install camshafts and timing belt, as outlined.

Oil Pan**Removal**

1. Raise vehicle. Refer to Section 10-04.
2. Drain engine oil.
3. Remove frame brace retaining bolt. Loosen RH A-arm front bolt and pivot brace downward.
4. Disconnect front exhaust pipe from exhaust manifold or turbocharger.
5. Remove front exhaust pipe bracket retaining bolts.
6. Loosen rubber exhaust hangers at catalyst. Allow exhaust to hang supported by mechanic's wire.
7. Disconnect turbocharger oil return hose, if required.
8. Remove oil pan retaining bolts.
9. Carefully pry oil pan loose from cylinder block.

CAUTION: Do not force a prying tool between cylinder block and oil pan.
10. Remove front and rear oil pan seals.

REMOVAL AND INSTALLATION (Continued)


**Installation**

1. Clean oil pan and cylinder block gasket surfaces.
2. Apply Gasket Sealant E3AZ-19562-A or equivalent to new front and rear oil pan seals. Install seals to cylinder block.
3. Apply Gasket Sealer E3AZ-19562-A or equivalent to oil pan gasket surface.
4. Install oil pan. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
5. Connect turbocharger oil return hose, if required.
6. Install rubber exhaust hanger to brackets.
7. Install new gasket and connect front exhaust pipe to exhaust manifold or turbocharger. Tighten retaining nuts to 31-46 N·m (23-34 lb-ft).
8. Install front exhaust pipe bracket. Tighten retaining bolts to 31-46 N·m (23-34 lb-ft).

9. Pivot frame brace into position. Tighten retaining bolt to crossmember to 35-50 N·m (26-37 lb-ft). Tighten RH A-arm front retaining bolt to 64-89 N·m (47-66 lb-ft).
10. Lower vehicle.
11. Fill engine oil. Start engine and check for leaks.

Oil Pump**Removal**

1. Remove timing belt, as outlined.
2. Remove oil pan, as outlined.
3. Remove crankshaft timing belt pulley.
4. Remove oil strainer / pickup tube.
5. Remove oil pump retaining bolts.


REMOVAL AND INSTALLATION (Continued)**6. Remove oil pump.****Installation**

1. Clean gasket surfaces.
2. Install oil pump with new gasket.
3. Install retaining bolts. Tighten to 19-25 N·m (14-19 lb-ft).
4. Install oil strainer / pickup with new gasket. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
5. Install crankshaft timing belt pulley. Tighten retaining bolt to 108-118 N·m (80-87 lb-ft).
6. Install oil pan, as outlined.
7. Install timing belt, as outlined.

Piston and Connecting Rod Assembly**Engine Installed****Removal**

1. Remove cylinder head, as outlined.


2. Remove oil pan, as outlined.
3. Remove connecting rod bearing cap retaining nuts.
4. Inspect top of cylinder wall and remove ridge using Ridge Reamer T64L-6011-EA or equivalent, if required.



5. Push rod and piston up from bottom and remove.
- NOTE: For inspection and service procedure, refer to Section 21-01.


Installation

1. Position compression rings at 30 degrees to each side of piston pin center line.




REMOVAL AND INSTALLATION (Continued)

2. Compress piston rings using Ring Compressor T81P-6002-C or equivalent. Install rubber hose over connecting rod studs to protect cylinder walls and crankshaft bearing surface.



3. Position piston and rod assembly in cylinder block. Notch on piston goes to front of engine, (timing belt).
4. Tap piston and rod assembly into cylinder using wooden tool handle.




5. Install connecting rod to crankshaft. Remove rubber hose.
6. Install connecting rod bearing cap. Tighten retaining nuts to 47-52 N-m (35-38 lb-ft).
7. Install oil pan, as outlined.


8. Install cylinder head, as outlined.
9. Start engine. Check for leaks and proper operation.

Camshaft Seals**Removal**

1. Remove timing belt, as outlined.
2. Remove camshaft pulley(s). Use wrench to hold camshaft while removing pulley retaining bolt.





3. Remove cover plate.
4. Remove camshaft seal(s) using Seal Puller T78P-3504-N or equivalent.

**Installation**

1. Lubricate seal lip(s) with clean engine oil.


REMOVAL AND INSTALLATION (Continued)

2. Install seal(s) using Seal Installer T90P-6256-BH and Seal Protector T90P-6256-AH or equivalent.



A13159-A

3. Install cover plate. Tighten retaining screws to 8-11 N·m (69-95 lb-in).
4. Install camshaft pulley(s). Install intake camshaft pulley with the "I" straight up, and the exhaust camshaft pulley with the "E" straight up. Tighten retaining bolt to 49-61 N·m (36-45 lb-ft). Hold camshaft with wrench to tighten pulley bolt.



A13161-A

5. Install timing belt, as outlined.

Crankshaft Oil Seal, Front**Removal**

1. Remove timing belt, as outlined.
2. Remove crankshaft timing belt pulley.
3. Remove crankshaft seal using Seal Remover T78P-3504-N or equivalent.

Installation

1. Lubricate seal lip with clean engine oil.
2. Install crankshaft seal using Front Crankshaft Seal Installer T87C-6019-A or equivalent.
3. Install timing belt pulley. Tighten retaining bolt to 108-118 N·m (80-87 lb-ft).
4. Install timing belt, as outlined.

Crankshaft Oil Seal, Rear**Removal**

1. Remove transaxle. Refer to Section 16-37, 16-38 or 17-27.
2. Remove clutch cover and disc, if required.
3. Remove flywheel.
4. Remove rear seal using Seal Remover T78P-3504-N or equivalent.

Installation

1. Lubricate seal lip with clean engine oil.
2. Install crankshaft seal using Rear Crankshaft Seal Installer T87C-6701-A and Screw Set T90P-6701-AH or equivalent.
3. Install flywheel. Apply Thread Sealer E0AZ-19554-AA or equivalent to flywheel retaining bolts. Tighten retaining bolts to 96-103 N·m (71-76 lb-ft).
4. Install clutch assembly, if required.
5. Install transaxle.

Core Plugs**Removal and Installation**

To remove a core plug, drill a 12.7mm (1/2-inch) hole in the center of the plug and remove with an Impact Slide Hammer T59L-100-B or T50T-100-A or equivalent or pry it out with a large drift punch. On a small core plug, drill a 6.35mm (1/4-inch) hole in the center of the plug and pry it out with a small pin punch. Clean and inspect the plug bore.

Prior to installing a core plug, the plug bore should be inspected for any damage that would interfere with the proper sealing of the plug. If the bore is damaged it will be necessary to true the surface by boring for the next specified oversize plug.


REMOVAL AND INSTALLATION (Continued)

Oversize (OS) plugs are identified by the OS stamped in the flat located on the cup side of the plug.

Coat the plug and / or bore lightly with an oil-resistant (oil galley) or Perfect Seal Sealing Compound B5A-19554-A (ESR-M18P2-A) or equivalent, and install it according to the following procedure:

Install the core plug with the flanged edge outward. The maximum diameter of this plug is located at the outer edge of the flange. The flange on cup-type plug flares outward with the largest diameter of the outer (sealing) edge.

The flanged (trailing) edge must be below the chamfered edge of the bore to effectively seal the plugged bore.



A13502-A

If the core plug replacing tool has a depth seating surface, do not seat the tool against a non-machined (casting) surface.

CAUTION: It is imperative to install the plug into the machined bore by using a properly designed tool. Under no circumstances is the plug to be driven into the bore using a tool that contacts the flange. This method will damage the sealing edge and will result in leakage and / or plug blowout.

DISASSEMBLY AND ASSEMBLY


Engine

NOTE: This procedure continues from Engine, Removal.

Disassembly


1. Remove intermediate axle shaft and bearing, if equipped.
2. Remove clutch, pressure plate and flywheel, if required.
3. Remove end plate.
4. Remove turbocharger inlet tube, if required.
5. Mount necessary brackets and mount engine to engine stand.

6. Disconnect vacuum hoses from intake manifold and throttle body.
7. Disconnect coolant and crankcase ventilation hoses from intake manifold.
8. Remove intake manifold and throttle body assembly.



A13153-A

9. Remove heat shields from exhaust manifold, and turbocharger, if equipped.
10. Disconnect oil lines and coolant hoses from turbocharger, if equipped.
11. Disconnect oil and coolant lines from turbocharger, if equipped.
12. Remove turbocharger support bracket retaining bolts, if equipped.
13. Remove exhaust manifold or manifold / turbocharger assembly. Cover all turbocharger openings.




A13165-A

14. Remove coolant bypass tube (heater tube).


DISASSEMBLY AND ASSEMBLY (Continued)

15. Remove distributor, spark plug wires and wire retainers.
16. Remove air bypass tube and bracket.
17. Remove oil filter and oil cooler, if equipped. Remove oil filter stud, if required.




A13169-A

18. Remove oil pressure sensor and remove knock sensor, if equipped.




A13170-A

19. Remove exhaust pipe support bracket.
20. Remove alternator and brackets.
21. Remove water pump pulley.
22. Remove crankshaft pulleys and baffle plate.
23. Remove timing belt covers.
24. Remove timing belt tension and idler pulleys, and tension spring.



A13171-A


25. Mark timing belt direction or rotation and remove timing belt.
26. Remove oil dipstick bracket retaining bracket and bolt.
27. Remove water pump outlet.
28. Remove water pump.



A13172-A

29. Remove cylinder head cover and gasket. Remove cylinder head.


NOTE: Loosen retaining bolts in the order shown.




A13173-A

DISASSEMBLY AND ASSEMBLY (Continued)

30. Remove RH engine mount bracket.
31. Remove crankshaft timing belt pulley.
32. Remove oil pan and seals.
CAUTION: Use care not to pry against sealing surfaces.
33. Remove oil pump pick-up tube.
34. Remove oil pump.





35. Remove rear crankshaft oil seal mounting flange.
36. Mark positions of connecting rods and pistons for assembly. Ensure main bearing caps and rod bearing caps are numbered, or mark them for assembly.
37. Remove connecting rod bearing caps.
38. Inspect the tops of cylinder walls for ridges. Remove ridges, using Ridge Reamer T64L-6011-EA or equivalent, if required.
39. Remove piston and connecting rod assemblies.
40. Remove crankshaft bearing caps and remove crankshaft.
41. Remove upper main bearings and thrust bearings.
42. Remove piston oil spray nozzles, if equipped.



NOTE: For engine block service, refer to Service Procedures in this Section.

Assembly


1. Install piston oil spray nozzles. Use new sealing washers. Tighten bolt/fitting to 12-18 N·m (104-156 lb-in).
2. Install upper main bearings and thrust bearings into cylinder block. Lubricate with clean engine oil. Oil grooves on thrust bearings must face crankshaft.



3. Position crankshaft into cylinder block.
4. Install lower main bearings into bearing caps. Install caps over crankshaft. Tighten retaining bolts to 54-59 N·m (40-43 lb-ft).
5. Install piston and connecting rod assemblies as follows:
 - a. Cover rod studs with rubber tubing to protect crankshaft and cylinder walls.


DISASSEMBLY AND ASSEMBLY (Continued)

- b. Position piston ring gaps at 30 degrees from piston pin centerline.




A13165-A

- c. Compress piston rings using Piston Ring Compressor D81L-6002-C or equivalent.
- d. Install upper connecting rod bearing inserts. Lubricate with clean engine oil. Lower piston assemblies into block, ensuring notches are to front (timing belt) of engine.



A13167-A

- e. Install lower rod bearing inserts into rod caps and lubricate with clean engine oil. Install rod caps. Tighten retaining nuts to 65-69 N·m (48-51 lb-ft).
6. Install rear crankshaft seal and mounting flange assembly with new gasket. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
7. Install oil pump assembly with new gasket. Tighten retaining bolts to 19-25 N·m (14-19 lb-ft).
8. Install oil strainer and pick-up tube with new gasket. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).




A13177-A

9. Apply Gasket Sealant E3AZ-19562-A or equivalent to front and rear oil pan seals. Install seals.

NOTE: Check oil pump and rear crank seal gaskets and trim away excess material that may cause interference with proper fit of oil pan.

10. Apply Gasket Sealant E3AZ-19562-A or equivalent to oil pan sealing surface. Install oil pan. Tighten retaining bolts to 6-9 N·m (52-78 lb-in).
11. Install oil pressure sensor. Tighten to 12-18 N·m (104-156 lb-in).
12. Install knock sensor (turbocharged vehicles). Tighten to 20-34 N·m (14-25 lb-ft).




A13178-A


13. Install oil cooler. Tighten retaining nut to 29-39 N·m (22-29 lb-ft).
14. If removed, install oil filter stud. Install oil filter. Lubricate seal with clean engine oil prior to installing. Tighten by hand only.

DISASSEMBLY AND ASSEMBLY (Continued)


15. Install crankshaft timing belt pulley. Tighten bolt to 108-118 N·m (80-87 lb-ft).
16. Ensure cylinder head gasket surfaces are clean and position new head gasket on cylinder block.
17. Position RH engine mount bracket.
18. Install cylinder head. Tighten retaining bolts in sequence shown first to 20-34 N·m (14-25 lb-ft), then to 76-81 N·m (56-60 lb-ft).




19. Install water pump with new gasket. Install water pump outlet, with new gasket, to water pump. Tighten retaining bolts to 19-25 N·m (14-19 lb-ft).



20. Install alternator bracket and engine mount support. Tighten retaining bolts as follows: No. 1 47-66 N·m (35-48 lb-ft); No. 2 60-85 N·m (44-63 lb-ft); No. 3 93-117 N·m (69-86 lb-ft); No. 4 37-52 N·m (27-38 lb-ft).





21. Install timing belt idler and tensioner pulleys. Tighten idler pulley retaining bolt only to 37-52 N·m (27-38 lb-ft).
22. Install tension spring. Fully extend tension spring and tighten tension pulley retaining bolt to 37-52 N·m (27-38 lb-ft).




DISASSEMBLY AND ASSEMBLY (Continued)

23. Align crankshaft and camshaft timing marks. Intake camshaft should have "I" mark aligned. Exhaust camshaft should have "E" aligned.




A13182-A

24. Install timing belt. Keep side opposite tensioner as tight as possible.
NOTE: If installing used belt, ensure belt is installed as marked during removal.
25. Rotate crankshaft two complete turns. Loosen tension pulley retaining bolt to allow spring to apply belt tension. Tighten pulley bolt to 37-52 N·m (27-38 lb-ft).
26. Rotate crankshaft two complete turns. Inspect timing marks. Remove belt and repeat procedure if not aligned properly.
27. Check belt tension. Deflection between camshaft pulleys should be between 8.5-11.5mm (0.33-0.45 inch).




A13184-A

28. Install lower, center and upper timing belt covers. Ensure gaskets are in place. Tighten retaining bolts to 8-11 N·m (69-95 lb-in). Install oil dipstick tube bracket. Tighten bolt to 8-11 N·m (69-95 lb-in).



A13183-A

29. Install water pump pulley. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
30. Install baffle plate and crankshaft pulleys. Tighten retaining screws and bolts to 12-17 N·m (109-152 lb-in).




A13185-A

31. Install alternator and alternator belt. Tighten adjustment bolt to 19-25 N·m (14-19 lb-ft). Tighten pivot bolt to 37-52 N·m (27-38 lb-ft). Tighten support bracket bolt to 37-52 N·m (27-38 lb-ft).
32. Install cylinder head cover and gasket. Tighten retaining bolts to 5-9 N·m (43-78 lb-in).
33. Install new O-ring to distributor. Lubricate with clean engine oil and install distributor. Secure retaining bolts but do not fully tighten. Install ignition wires and retainers.
34. Install intake manifold with new gasket.

DISASSEMBLY AND ASSEMBLY (Continued)

NOTE: Ensure coolant passage openings in gasket align with openings in manifold and cylinder head. Tighten retaining nuts and bolts to 19-25 N·m (14-19 lb-ft).




A13153-A

35. Install new O-ring to coolant bypass tube (heater bypass) and install tube to water pump outlet.
36. Install exhaust manifold gaskets.

NOTE: Two piece gaskets must be used. Heavier gasket installs first.

TURBO SHOWN
NATURALLY ASPIRATED TYPICAL



A13186-A

37. Install exhaust manifold. On turbocharged engines install as follows:
 - a. Install exhaust manifold / turbocharger / support bracket assembly. Tighten manifold retaining nuts to 39-57 N·m (29-42 lb-ft).
 - b. Tighten turbocharger support retaining bolts to 43-61 N·m (32-45 lb-ft).
 - c. Install oil pressure line to turbocharger. Use new sealing washers on bolt. Tighten to 12-18 N·m (104-156 lb-in). Connect oil return and coolant hoses.


38. On naturally aspirated engines, install exhaust manifold. Tighten retaining nuts to 39-57 N·m (29-42 lb-ft).
39. Install exhaust manifold (and turbocharger) heat shields.
40. Install front exhaust pipe support bracket. Tighten retaining bolts to 18-26 N·m (13-20 lb-ft).
41. Connect intake air bypass to the intake manifold (throttle body). Connect vacuum lines, air tubes and coolant hoses.

NOTE: Engine must be removed from engine stand to complete engine assembly. Remaining steps are outlined in Engine Installation.

Cylinder Head

Disassembly

1. Remove spark plugs.
2. Remove camshaft pulleys. Hold camshaft with wrench to remove pulley retaining bolts.




A13156-A

3. Remove distributor.
4. Remove seal plate.
5. Remove camshaft bearing cap retaining bolts.


CAUTION: Loosen retaining bolts alternately and evenly to prevent excessive stress to camshafts.
6. Remove camshaft bearing caps. Note numerical and directional positions for assembly.
7. Remove camshafts. Slide camshaft seals off ends of shafts.
8. Remove hydraulic lash adjusters (HLA). Set aside in order so they can be installed in the positions they are removed from.

DISASSEMBLY AND ASSEMBLY (Continued)


9. Remove valves, springs, keepers and seats using Valve Spring Compressor T89P-6565-A, Valve Spring Compressor Bar T87C-6565-A, and Valve Spring Compressor Brackets T90P-6565-AH or equivalent.



10. Remove valve stem seals using Valve Stem Seal Remover T89P-6510-D or equivalent.



11. Tap out valve guides from combustion chamber side, using Valve Guide Remover T89P-6510-A or equivalent.




NOTE: For cylinder head service refer to Service Procedures in this Section.

Assembly

1. Fit circlip onto valve guide, if required.
2. Install valve guides using Valve Guide Remover T89P-6510-A or equivalent. Tap into head until exposed height is 16.8-17.4mm (0.661-0.685 inch).

CAUTION: Tap lightly or circlip will be damaged and valve guide will not be secure in cylinder head.




DISASSEMBLY AND ASSEMBLY (Continued)

NOTE: Although the shapes of the intake and exhaust valve guides are different, the exhaust valve guides are used on both sides as replacements.




INTAKE



EXHAUST

A13503-A


3. Lubricate valve stem seals with clean engine oil and install using Valve Stem Seal Replacer T89P-6510-AH or equivalent. Set seal into tool and tap lightly onto guide boss until seated.



A13191-A

4. Install valves in their original locations, unless replacing with new valves.

5. Install valves, springs, spring seats and keeper using spring compressor tools outlined in Disassembly.
6. Install hydraulic lash adjusters into their original locations.
7. Install camshafts. Apply clean engine oil to bearing surfaces. Install camshaft oil seals.
8. Apply light amount of Gasket Sealant E3AZ-19562-A or equivalent to front camshaft bearing caps.
9. Install camshaft bearing caps in their original locations. Tighten retaining bolts to 11-14 N·m (100-126 lb-in) in sequence shown.



A13192-A


10. Install seal plate. Tighten retaining bolts to 8-11 N·m (69-95 lb-in).
11. Install distributor.
12. Install camshaft pulleys. Install intake cam with the "I" straight up and the exhaust cam with the "E" straight up. Hold camshaft with wrench to tighten camshaft retaining bolt. Tighten retaining bolt to 49-61 N·m (36-45 lb-ft).
13. Install spark plugs.

Subassemblies**Piston and Connecting Rod****Disassembly**

1. Remove piston pin retaining clips.
2. Position piston and connecting assembly on Piston Pin Remover and Installer D90P-6135-AH or equivalent.

DISASSEMBLY AND ASSEMBLY (Continued)

3. Drive out piston pin.




A13183-A

4. Remove piston rings using suitable piston ring remover.

NOTE: For piston connecting rod service, refer to Service Procedures as outlined.


Assembly

1. Install piston rings as follows:
- Install three piece oil control rings. Install the spacer ring first then the upper and lower rails. Position end gaps as shown.



A13184-A

- b. Install second and top rings. Ensure the scraper faces downward on the second rings and the identification mark faces upward on both piston rings. Position end gaps as shown.



A13185-A


2. Position piston and rod in Piston Pin Remover / Installer D90P-6135-AH or equivalent. Drive piston pin into piston. Install piston pin retaining clips.
3. Ensure piston pivots freely on connecting rod.

Oil Pump**Disassembly**

- Remove oil pump cover.
- Remove outer and inner rotors.
- Remove cotter pin and remove pressure piston, cap and spring.

DISASSEMBLY AND ASSEMBLY (Continued)

4. Remove oil seal if required using Seal Remover T78P-3504-N or equivalent.




A13197-A

NOTE: For oil pump service, refer to Service Procedures as outlined.

Assembly

1. Install oil seal. Press into place until flush with pump body.




A13196-A

2. Install pressure piston, cap and spring with new cotter pin.
3. Install inner and outer rotors.
4. Install oil pump cover. Tighten screws to 19-25 N·m (14-19 lb-ft).

Flywheel, Pilot Bearing**Removal**


Using a suitable driver, tap out bearing toward front (crankshaft) of flywheel.

Flywheel Bearing Removal

A13199-A

Installation

Using a suitable driver, tap new bearing into flywheel from clutch side.

Flywheel Bearing Installation

A13200-A

SERVICE PROCEDURES**Service Limit Specifications**

Service limit specifications are intended to be a guide only, to be used when overhauling or reconditioning an engine or engine component. A determination can be made whether a component is suitable for continued service or should be replaced for extended service while the engine is disassembled.

Cylinder Block**Cleaning**

After any cylinder bore service operation, such as honing or deglazing, clean the bore(s) with soap or detergent and water. Then, thoroughly rinse the bore(s) with clean water to remove the soap or detergent, and wipe the bore(s) dry with a clean, lint-free cloth. Finally, wipe the bore(s) with a clean cloth dipped in engine oil.

SERVICE PROCEDURES (Continued)**CAUTION: If these procedures are not followed, rusting of the cylinder bore(s) may occur.**

If the engine is disassembled, thoroughly clean the block with solvent. Remove old gasket material from all machined surfaces. Remove all pipe plugs that seal oil passages, clean out all the passages. Blow out all passages, then bolt holes, etc., with compressed air. Ensure threads in the cylinder head bolt holes are clean. Dirt in the threads may cause binding and result in a false torque reading. Use a tap to true-up threads and to remove all deposits. Thoroughly clean the grooves in the crankshaft bearings and bearing retainers.

Inspection

After the block has been thoroughly cleaned, check it for cracks. Tiny cracks not visible to the naked eye may be detected by coating the suspected area with a mixture of 25 percent kerosene and 75 percent light engine oil. Wipe the part dry and immediately apply a coating of zinc oxide dissolved in wood alcohol. Do not use rubbing alcohol as a substitute. If cracks are present, the coating will become discolored at the damaged area. Replace the block if it is cracked.

Check all machined surfaces for burrs, nicks, scratches and scores. Remove minor imperfections with an oil stone.

Replace all plugs that show evidence of leakage. Inspect the cylinder walls for scoring, roughness or other signs of wear. Check the cylinder bore for out-of-round and taper. Measure the bore with an accurate bore gauge following the instructions of the manufacturer. Measure the diameter of each cylinder bore at the top, middle and bottom with the gauge placed at right angles and parallel to the centerline of the engine. NOTE: Use only the measurements obtained at 90 degrees to the engine centerline when calculating the piston-to-cylinder bore clearance.

Servicing Sand Holes or Porous Engine Castings

Porosity or sand hole(s), which will cause oil seepage or leakage, can occur with modern casting processes. A complete inspection of engine and transmission should be made. If the leak is attributed to the porous condition of the cylinder block or sand hole(s), service can be made with Ford Metallic Plastic C6AZ-19554-A (M3D35-A(E)) or equivalent.

CAUTION: Do not service cracks with this material.

Service with this metallic plastic must be confined to those cast iron engine component surfaces where the inner wall surface is not exposed to engine coolant pressure or oil pressure. For example:

1. Cylinder block surfaces extending along the length of the block, upward from the oil pan rail to the cylinder water jacket, but not including machined areas.
2. Lower rear face of the cylinder block.
3. Intake manifold casting. Service is not recommended to the intake manifold exhaust crossover section, since temperatures can exceed the recommended temperature limit of 260°C (500°F).
4. Cylinder front cover on engines using cast iron material.
5. Cylinder head, along the cylinder head cover gasket surface.

The following procedure should be used to service porous areas or sand holes in cast iron.


1. Clean surface to be serviced by grinding or rotary filing to a clean bright metal surface. Chamfer or undercut hole or porosity to a greater depth than rest of cleaned surface. Solid metal must surround hole. Openings larger than 6.35mm (1/4-inch) should not be serviced using metallic plastic. Openings in excess of 6.35mm (1/4-inch) can be drilled, tapped and plugged using common tools. Clean service area thoroughly. Metallic plastic will not stick to a dirty or oily surface.
2. Mix metallic plastic base and hardener as directed on container. Stir thoroughly until uniform.
3. Apply service mixture with a suitable clean tool (putty knife, wood spoon, etc.) forcing epoxy into hole or porosity.
4. Allow service mixture to harden. This can be accomplished by two methods. Heat cure with a 250-watt lamp placed 254mm (10 inches) from serviced surface, or air-dry for 10-12 hours at temperatures above 10°C (50°F).
5. Sand or grind serviced area to blend with general contour of surrounding surface.
6. Paint the surface to match the rest of the block.

Cylinder Block Flatness


1. Inspect the cylinder block for the following. Service or replace the cylinder block as necessary.
 - a. Leakage damage.
 - b. Cracks.
 - c. Scoring of cylinder wall.

SERVICE PROCEDURES (Continued)

2. Measure flatness using Straight Edge D83L-4201-A or equivalent, on top surface of cylinder block in the six directions as illustrated.



A13514-A



A13515-A


3. If the distortion exceeds 0.15mm (0.006 inch) MAX., repair by machining or replace the cylinder block.

NOTE: Maximum machine limit for cylinder block is 0.20mm (0.008 inch).

Cylinder Bores

Taper / Out-of-Round

1. Measure the cylinder bores in X and Y directions at three levels (A, B, and C) in each cylinder as illustrated. Compare measurement readings with specifications.



A13516-A

NOTE: If cylinder bore exceeds the maximum limit, refinish the cylinder to oversize.

2. If the difference between measurements A and C exceeds 0.019mm (0.0007 inch) taper, rebore the cylinder to oversize.
3. If the difference between measurements X and Y exceeds 0.019mm (0.0007 inch) out-of-round, rebore the cylinder to oversize.

CAUTION: The boring size should be based on the size of an oversize piston and be the same for all cylinders.

Honing is recommended for refinishing cylinder walls only when no crosshatch pattern is visible on cylinder walls, or for fitting pistons to the specified clearance. The grade of hone to be used is determined by the amount of metal to be removed. Follow the instructions of the hone manufacturer. If coarse stones are used to start the honing operation, leave enough material so that all hone marks can be removed with the finishing hone which is used to obtain the proper piston clearance. After honing, thoroughly clean cylinder bores with a detergent and water solution.

Cylinder walls that are severely marred and / or worn beyond the specified limits should be refinished.

CAUTION: Before any cylinder is refinished, all main bearing caps must be in place and tightened to the proper torque so that the crankshaft bearing bores will not become distorted from the refinishing operation.

If the cylinder will not clean up when refinished for the maximum oversize piston recommended, replace the block.

Refinish the cylinder to within approximately 0.038mm (0.0015 inch) of the required oversize diameter. This will allow enough stock for the final step of honing so that the correct surface finish and pattern are obtained. For the proper use of the refinishing equipment, follow the instructions of the manufacturer.

CAUTION: Only experienced personnel should perform this work.

Use a motor-driven, spring pressure-type Cylinder Hone Set T73L-6011-A or equivalent, hone at a speed of 300-500 rpm. Hones of grit sizes 180-220 will normally provide the desired bore surface finish of 18-38 AA.


SERVICE PROCEDURES (Continued)

When honing the cylinder bores, use a lubricant mixture of equal parts of kerosene and SAE No. 20 motor oil. Operate the hone in such a way as to produce a crosshatch finish on the cylinder bore. The cross-hatch pattern should be at an angle of approximately 30 degrees to the cylinder bore. After the final operation in either of the two refinishing methods described and prior to checking the piston fit, thoroughly clean with a detergent and water solution and then oil the cylinder walls. Mark the pistons to correspond to the cylinders in which they are to be installed. When the refinishing of all cylinders that require it has been completed and all pistons are fitted, thoroughly clean the entire block and oil the cylinder walls.

Refinish cylinders that are deeply scored, out-of-round, and / or taper exceeds specification. If the cylinder walls have minor surface imperfections, but the out-of-round and taper are within limits, it may be possible to remove the imperfections by honing the cylinder walls and installing new service piston rings, providing the piston clearance is within specification.

Ridge Reaming

If upper part of a cylinder wall shows uneven wear, remove the ridge with Ridge Reamer T64L-6011-EA or equivalent.




A14251-A

Pistons, Piston Rings and Piston Pins

Pistons

Carefully inspect the pistons for fractures at the ring lands, skirts, oil ring slot corners, and pin bosses, and for scuffed, rough or scored skirts. Clean piston ring grooves using Piston Ring Groove Cleaner D61L-6002-D or equivalent. If the lower inner portion of the ring grooves have a high step, replace the piston. The step will interfere with ring operation and cause excessive ring side clearance.




A14293-A

Spongy, eroded areas near the edge of the top of the piston are usually caused by detonation or pre-ignition. A shiny surface of the thrust surface of the piston, offset from the centerline between the piston pin holes, can be caused by a bent connecting rod. Replace pistons that show signs of excessive wear, wavy ring lands, fractures or damage from detonation or pre-ignition.

NOTE: When replacing piston(s), piston rings must also be replaced.

1. Inspect outer surfaces of piston(s) for seizure or scoring. Replace piston(s) if required.
2. Measure the outer diameter of each piston at right angles to the piston pin. Make the measurement 16.5mm (0.650 inch) below the lowest oil ring groove bottom edge.




A14266-A

3. Measure the cylinder bore diameter as outlined in Cylinder Block Service Procedures. Calculate piston-to-cylinder clearance. If clearance exceeds the maximum specification, replace the pistons, and / or rebore the cylinder block as necessary.

SERVICE PROCEDURES (Continued)


Pistons and Piston Rings

1. Measure the piston ring-to-ring land clearance around entire piston circumference using a new piston ring and a feeler gauge. If the clearance exceeds maximum specification, replace the piston.




Piston and Piston Pin

1. Measure piston pin bore diameter in X and Y directions at four points as shown.



2. Measure piston pin diameter in X and Y directions at four points as shown.




PIN DIAMETER: 19.987-19.993mm
(0.0002-0.0005 INCH)

A14272-A

3. Calculate piston-to-pin clearance. If clearance exceeds 0.005-0.013mm (0.0002-0.0005 inch), replace piston and / or piston pin as required.

Piston Rings

1. Insert a new piston ring into cylinder bore. Use a piston and push the piston ring to the bottom of ring travel in the cylinder.




A14269-A

2. Measure piston ring end gap. Repeat measuring steps for all rings in each cylinder bore. Replace rings if gap exceeds maximum specification.


SERVICE PROCEDURES (Continued)

Connecting Rod


1. Measure each connecting rod bushing inner diameter in two directions.





2. Measure piston pin diameter as outlined.
3. Calculate piston pin-to-connecting rod bushing clearance. Clearance should not exceed 0.010-0.027mm (0.0004-0.0011 inch).
4. Install connecting rod on a holding fixture for checking straightness. Maximum deviation should not exceed 0.075mm (0.0030 inch). If out of specification, replace connecting rod.

**Crankshaft**

1. Check crankshaft bearing and seal surfaces for damage and scoring. Inspect oil holes for clogging. Clean crankshaft in solvent, blow out all oil passages with air.
2. Set crankshaft on V-blocks and measure runout at center journal using a dial indicator. If runout exceeds 0.04mm (0.0016 inch) replace crankshaft.



3. Measure each crankpin and bearing journal in two directions. If diameters are less than minimum, machine journals to match on undersized bearing.



CAUTION: Do not remove fillet area (dimension R) when machining the crankshaft.

NOTE: Undersize bearings are available in the following dimensions:

- 0.25mm (0.010 inch)
- 0.50mm (0.020 inch)

SERVICE PROCEDURES (Continued)

Crankshaft and Connecting Rod Bearings


Bearings that are to be reused should be identified so they can be installed in their original locations.

Clean the bearing inserts and caps thoroughly in solvent, and dry them with compressed air.

CAUTION: Do not scrape gum or varnish deposits from the bearing shells with a sharp tool.

Inspection

Inspect each bearing carefully. Bearings that have a scored, chipped or worn surface should be replaced. Typical examples of unsatisfactory bearings and their causes are shown in the illustration. The copper lead bearing base may be visible through the bearing overlay. If the base showing is less than 20 percent of the total area, the bearing is not excessively worn. It is not necessary to replace the bearing if the bearing clearance is within recommended limits. Check the clearance of bearings that appear to be satisfactory with Plastigage as outlined.




Crankshaft Oil Clearance

1. Install upper main bearings and thrust bearings in cylinder block.


2. Install crankshaft.
3. Position Plastigage at the high point of the journals.
4. Install lower main bearings and caps.
5. Tighten main bearing cap retaining bolts to 54-59 N·m (40-43 lb-ft) in sequence shown. Tighten in two or three steps.

NOTE: Do not rotate crankshaft while Plastigage is being used. A false reading or no reading will result.



A14280-A

6. Remove bearing caps. Measure Plastigage using measuring guide. If clearance exceeds specification, the crankshaft must be machined and undersized bearings fitted.




A14281-A

Crankshaft End Play

1. Apply clean engine oil to crankshaft main bearing journals and to main bearing surfaces.


SERVICE PROCEDURES (Continued)

2. Install crankshaft and thrust bearings. Tighten main bearing caps in sequence shown to 54-59 N·m (40-43 lb·ft). Tighten in two or three steps.



A14280-A

3. Using a dial indicator, measure end play by moving crankshaft fully forward to fully rearward. Repeat several times to ensure correct reading.
4. Crankshaft end play should be 0.080-0.282mm (0.0031-0.011 inch), not to exceed 0.30mm (0.0118 inch).




A14284-A

5. If end play exceeds maximum specification, machine crankshaft and install oversize thrust bearings, or replace crankshaft.


Oil Pump

1. Disassemble oil pump as outlined.
2. Thoroughly clean all parts.
3. Inspect pressure spring for weakness or breakage.
4. Inspect pressure spring free length. Spring should measure 45.5mm (1.791 inch). Replace spring if required.




A14287-A

5. Measure inner to outer rotor clearance as shown. If measurement exceeds 0.20mm (0.0079 inch), replace rotors or oil pump.



A14288-A


6. Measure outer rotor to pump body clearance. If measurement exceeds 0.22mm (0.0087 inch), replace rotors or pump.



A14289-A

SERVICE PROCEDURES (Continued)


7. Measure rotor to pump cover clearance using a straight edge as shown. If measurement exceeds 0.14mm (0.0055 inch), replace rotors or pump.



A14290-A

Oil Jet

1. Push the check ball and verify that it moves smoothly.
2. Blow through the oil jet and verify that air flows.



A14265-A

Cylinder Head

Replace the head if it is cracked. Remove all burrs or scratches with an oil stone.

Cleaning

With the valves installed to protect the valve seats, remove deposits from the combustion chambers and valve heads with a scraper and a wire brush.

CAUTION: Be careful not to damage the cylinder head gasket surface.

After the valves are removed, clean the valve guide bores. Use cleaning solvent to remove dirt, grease and other deposits from the valves with a fine wire brush or buffing wheel.

Inspection


Inspect the cylinder heads for cracks or excessively burned areas in the exhaust outlet ports.

Check the cylinder head for cracks and inspect the gasket surface for burrs and nicks. Small imperfections of this type can be dressed down using an oil stone. Replace the head if it is cracked.


The following inspection procedures are for a cylinder head that is to be completely overhauled. For individual repair operations, use only the pertinent inspection procedure.

Cylinder Head Flatness

1. Inspect the cylinder head for damage, cracks and leakage of water and oil. Replace the cylinder head if necessary.
2. Measure the cylinder head flatness using Straight Edge D83C-4201-A or equivalent in six directions as illustrated.



A13518-A



A13519-A

NOTE: Before machining the cylinder head, check the following and service or replace the cylinder head as necessary.


- Sinking of valve seats.
- Damage of manifold contact surface.
- Camshaft oil clearances and end play.

3. If the cylinder head flatness exceeds 0.15mm (0.006 inch) machine the cylinder head surface.

NOTE: Maximum machine limit for cylinder head is 0.20mm (0.008 inch).

SERVICE PROCEDURES (Continued)


4. Measure the intake and exhaust manifold contact flatness in the four directions as illustrated.




5. If distortion exceeds 0.15mm (0.006 inch), machine the surface or replace the cylinder head.

Valve and Valve Guide


1. Inspect each valve for the following. Replace or resurface the valve as necessary.
 - a. Damaged or bent stem.
 - b. Rough or damaged face.
 - c. Damaged or unevenly worn stem tip.
2. Measure the valve head margin thickness of each valve. Replace the valve if margin thickness is less than 5.0mm (0.020 inch).




3. Measure the overall length of each valve. Refer to Specifications.
4. Measure the stem diameter of each valve at points shown. Refer to Specifications.



5. Measure the inner diameter of each valve guide at the points shown.




6. Calculate the valve stem to guide clearance. Subtract the outer diameter of the valve stem from the inner diameter of the corresponding valve guide.



7. If the clearance exceeds specification, replace the valve and / or valve guide.

SERVICE PROCEDURES (Continued)


8. Measure the height of each valve guide. Replace the valve guide if necessary.



A13525-A

Valve Seat

1. Inspect the contact surface of each valve seat and valve face for roughness and /or damage.
2. If necessary, resurface the valve seat with a 45 degree valve seat cutter and /or resurface the valve face.
3. Apply a thin coat of Prussian blue to the valve face.
4. Inspect the valve seating by pressing the valve against the seat.
If blue does not appear 360 degrees around the valve face, replace the valve.
If blue does not appear 360 degrees around the valve seat, resurface the seat.
5. Measure the seat contact width. Measurement must be 0.8-1.4mm (0.031-0.055 inch).




A14252-A

6. Verify that the valve seating position is at the center of the valve face.

If the seating position is too high, correct the valve seat with a 70 degree cutter and a 45 degree cutter.

If the seating position is too low, correct the intake valve seat with a 35 degree cutter and a 45 degree cutter. Correct the exhaust valve seat with a 15 degree cutter and a 45 degree cutter.




A13626-A

7. Seat the valve to the valve seat with lapping compound.
8. Measure the protruding length (dimension L in illustration) of the valve stem. Measurement should be 43.5mm (1.713 inch).

If measurement is 43.5-44.0mm (1.713-1.732 inch), no correction needed.

If measurement is 43.5-44.0mm (1.713-1.732 inch), adjust with washer on spring seat area of cylinder head.

If measurement is 45.0mm (1.772 inch) or more, replace cylinder head.




A14254-A

Valve Spring


1. Inspect each valve spring for cracks or damage.

SERVICE PROCEDURES (Continued)

2. Measure the free length and out-of-square. Replace the valve spring if necessary.




A14255-A



A14256-A


Camshaft

1. Set the front and rear journals on V-blocks.
2. Measure the camshaft runout. If runout exceeds 0.03mm (0.0012 inch), replace camshaft.




A14275-A

3. Inspect the camshaft for wear or damage. Replace the camshaft if necessary.
4. Measure the cam lobe heights at the two points as shown. Replace camshaft if any measurement is below minimum specification.



A14258-A

5. Measure the journal diameters in X and Y directions at the two points (A and B) shown. Replace camshaft if out-of-round exceeds specification.




A14259-A

6. Measure the camshaft oil clearance as follows:
NOTE: Do not install hydraulic lash adjuster (HLA) for this procedure.
 - a. Remove all foreign material and oil from the journals and bearing surface.
 - b. Set the camshaft onto the cylinder head.
 - c. Position Plastigage atop the journals in the axial direction.
 - d. Install the camshaft caps according to the cap number and arrow mark.

SERVICE PROCEDURES (Continued)


- e. Install cap retaining bolts. Tighten in sequence shown to 11-14 N·m (97-123 lb-in). Tighten in two steps.

CAMSHAFT TIGHTENING SEQUENCE



A14260-A

- f. Loosen bearing cap bolts in two or three steps in sequence shown.




CAMSHAFT LOOSENING SEQUENCE

A14261-A


- g. Remove caps and measure Plastigage. This will give the oil clearance. If measurement exceeds 0.15mm (0.006 inch), replace cylinder head.

PLASTIGAGE GUIDE



A14262-A

- h. Using Dial Indicator TOOL-4201-C or equivalent, measure camshaft end play. Camshaft should set in cylinder head without HLA or bearing caps installed. If end play exceeds 0.20mm (0.008 inch), replace the camshaft and/or the cylinder head.




A14263-A

HLA

CAUTION: Do not attempt to repair the HLA.

1. Inspect the HLA friction surfaces for wear or damage. Replace the HLA if necessary.
2. Hold the bucket body and press the plunger by hand. If the plunger moves, replace the HLA.



A14264-A

SPECIFICATIONS

TORQUE SPECIFICATIONS

Description	N·m	Lb·Ft	Description	N·m	Lb·Ft
Shift Linkage Rod — Nut	16-22	12-17	RH Engine Mount Body Bracket — Bolt (1)	67-91	49-67
Shifter Stabilizer — Nut	31-46	23-34	RH Engine Mount Through Bolt	45-65	33-48
Engine End Plate — Screw	8-11	69-95*	Front Engine Mount to Transmission — Bolt	37-52	27-38
Flywheel — Bolt	96-103	71-76	Front Engine Mount — Nut	64-89	47-66
Clutch Pressure Plate — Bolt	18-26	13-19	Rear Engine Mount — Bolt	37-52	27-38
Torque Converter — Bolt	34-49	25-36	Rear Engine Mount — Nut	64-89	47-66
Intermediate Axle Shaft Bearing Support — Bolt	37-52	27-38	Exhaust Manifold — Nut	39-57	29-42
Manual Transaxle to Engine — Bolt (Upper)	89-117	66-86	Intake Manifold — Nut	19-25	14-19
Manual Transaxle Engine — Bolt (Lower)	37-52	27-38	Intake Manifold — Bolt	19-25	14-19
Automatic Transaxle to Engine-Bolt (Upper)	55-80	41-59	Cylinder Head — Bolt ①	76-81	56-60
Torque Converter Cover Plate — Bolt	7-10	61-87*	Cylinder Head Cover — Bolt	8-11	69-95*
Gusset Plate — Bolt	37-52	27-38	Timing Belt Pulley — Bolt	37-52	27-38
Starter — Bolt	31-46	23-34	Timing Belt Covers — Bolt	8-11	69-95*
Support Bracket, Intake Manifold — Bolt	31-46	23-34	Seal Plate — Bolt	8-11	69-95*
Starter Bracket to Support Bracket — Bolt	19-25	14-19	Camshaft Pulley	49-61	36-45
Shift Cable Pivot, (Automatic) — Nut	44-64	33-47	Crankshaft Main Bearing — Bolt	54-59	40-43
Shift Cable Retaining Bolt	8-11	69-95*	Connecting Rod Bearing — Nut	47-52	35-38
Front Exhaust Pipe to Support Bracket — Bolt	43-61	32-45	Crankshaft Rear Seal Flange — Bolt	8-11	69-95*
Exhaust Pipe to Manifold — Nut	39-57	29-42	Crankshaft Timing Pulley — Bolt	108-118	80-87
Chassis Cross Brace — Bolt	35-50	26-37	Crankshaft Pulley — Bolt	12-17	109-152*
A-Arm Front Bolt	97-117	69-86	Oil Pan — Bolt	8-11	69-95*
Wheel Lug Nuts	90-120	67-88	Oil Pump Assembly — Bolt	19-25	14-19
Ball Joint	43-54	32-40	Oil Pump Pick-up — Bolt	8-11	69-95*
A/C Compressor — Bolt	39-54	30-40	Oil Pump Cover	19-25	14-19
Power Steering Pump Bracket — Nut	47-66	35-48	Camshaft Bearing — Bolt	11-14	100-126*
Power Steering Pump Bracket — Bolt	47-66	35-48	Oil Spray Nozzle — Bolt	12-18	104-156*
Power Steering — Adjusting Nut	37-52	27-38	Oil Pressure Sensor	12-18	104-156*
Power Steering — Pivot Bolt	31-46	23-34	Knock Sensor	20-34	14-25
Radiator Bracket — Bolt	8-11	69-95*	Oil Cooler — Nut	29-39	22-29
RH Engine Mount Body Bracket — Bolt (3)	20-28	14-21	Water Pump, Outlet Bolt	19-25	14-19
			Water Pump Pulley Bolt	8-11	69-95*

* Lb-In

① Tighten first to 20-34 N·m (14-25 Lb·Ft), in sequence, then to 76-81 N·m (56-60 Lb·Ft).

CA13504-A

SPECIFICATIONS (Continued)

GENERAL SPECIFICATIONS	
DISPLACEMENT	1597cc (97.4 cu. inch)
NUMBER OF CYLINDERS	4
BORE AND STROKE	
Bore	78mm (3.07 inch)
Stroke	83.6mm (3.29 inch)
FIRING ORDER	1-3-4-2
CYLINDER HEAD AND VALVE TRAIN	
COMBUSTION CHAMBER DESIGN	PENT-ROOF
VALVE GUIDE HEIGHT	16.8-17.4mm (.661-.685 inch)
VALVE GUIDE BORE DIAMETER	
Intake and Exhaust	6.01-6.03mm (.2366-.2374 inch)
VALVE SEATS	
Width	
Intake	0.8-1.4mm (.0315-.0551 inch)
Exhaust	0.8-1.4mm (.0315-.0551 inch)
Angle	45°
VALVE STEM TO GUIDE CLEARANCE	
Intake	0.025-0.060mm (.0010-.0024 inch)
Exhaust	0.30-0.65mm (.0012-.0026 inch)
VALVE HEAD DIAMETER	
Intake	30.9-31.1mm (1.217-1.224 inch)
Exhaust	26.1-26.3mm (1.028-1.035 inch)
VALVE FACE ANGLE	45°
VALVE MARGIN	
Thickness-Minimum	
Intake	0.5mm (.020 inch)
Exhaust	0.5mm (.020 inch)
VALVE LENGTH	
Intake	105.29mm (4.1452 inch)
Minimum	104.8mm (4.126 inch)
Exhaust	105.39mm (4.1492 inch)
Minimum	104.9mm (4.130 inch)
VALVE STEM DIAMETER	
Intake	5.970-5.985mm (.2350-.2356 inch)
Exhaust	5.965-5.980mm (.2348-.2354 inch)
VALVE SPRINGS	
Free Length	47.2mm (1.858 inch)
Minimum	45.8mm (1.803 inch)
Out of Square-Maximum	1.6mm (.063 inch)
Setting Load/Height	196 N/40mm (44 lb/1.54 inch)
VALVE HLA BORE CLEARANCE	
Intake	0.025-0.066mm (.0010-.0026 inch)
Exhaust	0.025-0.066mm (.0010-.0026 inch)
CAMSHAFT	
Journal Diameter	25.940-25.965mm (1.0213-1.0222 inch)
Out-of-Round Maximum	0.05mm (.002 inch)
LOBE LIFT	
Intake	40.888mm (1.6098 inch)
Minimum	40.688mm (1.6019 inch)
Exhaust	40.888mm (1.6098 inch)
Minimum	40.688mm (1.6019 inch)
Wear Limit	40.489mm (1.5940 inch)
RUNOUT	0.03mm (.0012 inch)
ENDPLAY	0.07-0.19mm (.0028-.0075 inch)
Maximum	.2mm (.008 inch)
Bearing Oil Clearance	0.035-0.081mm (.0014-.0032 inch)
Maximum	.015mm (.0059 inch)
CYLINDER BLOCK	
HEIGHT	206.5mm (8.130 inch)
Cylinder Head Flatness Maximum Limit	0.15mm (.006 inch)
Maximum Resurface Grinding	0.20mm (.008 inch)
CYLINDER BORE DIAMETER	78.000-78.019mm (3.0709-3.0717 inch)
SERVICE LIMIT	
Standard Size	78.000-78.019 (3.0709-3.0717)
0.25 (0.010) Oversize	78.250-78.269 (3.0807-3.0815)
0.50 (0.020) Oversize	78.500-78.519 (3.0905-3.0913)
Taper	.019mm (.0007 inch)
Out-of-Round	.019mm (.009 inch)
CRANKSHAFT	
MAIN BEARING JOURNAL DIAMETER	49.938-49.956mm (1.9661-1.9668)
0.25 (0.010) Standard	49.688-49.706 (1.9562-1.9569)
Undersize Minimum	49.64 (1.954)
0.50 (0.020) Standard	49.438-49.456 (1.9464-1.9471)
Undersize Minimum	49.39 (1.944)
Maximum Out-of-Round	0.05mm (.020 inch)
Maximum Taper	0.05mm (.020 inch)
CONNECTING ROD JOURNAL DIAMETER	44.940-44.956mm (1.7693-1.7699 inch)
CRANKPIN DIAMETER	
Standard Size	
Standard	44.940-44.956 (1.7693-1.7699)
Minimum	44.89 (1.767)
0.25 (0.010) Undersize	
Standard	44.690-44.706 (1.7594-1.7601)
Minimum	44.64 (1.757)
0.50 (0.020) Undersize	
Standard	44.440-44.456 (1.7496-1.7502)
Minimum	44.39 (1.748)
Maximum Out-of-Round	0.05mm (.020 inch)
Maximum Taper	0.05mm (.020 inch)
CRANKSHAFT RUNOUT-MAXIMUM	0.04mm (.0016 inch)
MAIN BEARINGS	
Oil Clearance	0.024-0.042mm (.0010-.0017 inch)
Maximum	0.08mm (.0031 inch)
Undersize	0.25mm (0.010 inch) 0.50mm (0.020 inch)
CONNECTING ROD BEARINGS	
Oil Clearance	0.028-0.068mm (.0011-.0027 inch)
Maximum	0.10mm (.0039 inch)
THRUST BEARING	
Width	
Standard	2.500-2.550mm (.984-1.004 inch)
End Play	0.080-0.282mm (.0031-.011 inch)
Maximum	0.30mm (.0118 inch)
CONNECTING ROD	
CONNECTING ROD	
Piston Pin Bore Diameter	20.003-20.014mm (0.7875-0.7880 inch)
Crankshaft Bearing Bore Diameter	48.000-48.016mm (1.8898-1.8904 inch)
Length (Center-to-Center)	132.85-132.95mm (5.230-5.234 inch)
ALIGNMENT (BORE-TO-BORE MAX. DIFF)	
Bending	0.198mm (.0078 inch)
SIDE CLEARANCE (ASSEMBLED TO CRANK)	
Standard	0.110-0.262mm (.0043-.0103 inch)
Maximum	0.30mm (.012 inch)

CA13507-A

SPECIFICATIONS (Continued)

PISTONS

DIAMETER	77.954-77.974mm (3.0690-3.0698 inch)
0.25 (0.010) Oversize	78.204-78.224 (3.0789-3.0797)
0.50 (0.020) Oversize	78.454-78.474 (3.0887-3.0895)
PISTON-TO-BORE CLEARANCE	0.026-0.065mm (.0010-.0026 inch)
Maximum	0.15mm (.0059 inch)
PISTON RING GROOVE WIDTH	
Thickness	
Top	1.520-1.535mm (.0598-.0604 inch)
Second	1.520-1.535mm (.0598-.0604 inch)
Oil	4.120-4.040mm (.1583-.1591 inch)
PISTON RINGS	
Thickness	
Top	1.471-1.49mm (.0579-.0587 inch)
Second	1.471-1.49mm (.0579-.0587 inch)
Oil	4.015-4.035mm (.1580-.1588 inch)
Ring Gap	
Top	0.20-0.40mm (.008-.0157 inch)
Second	0.15-0.30mm (.0059-.0118 inch)
Oil	0.20-0.70mm (.008-.028 inch)
Side Clearance Limit	
Top	0.030-0.065mm (.0012-.0026 inch)

PISTONS — (Continued)

Second	0.030-0.065mm (.0012-.0026 inch)
Oil	0.030-0.065mm (.0012-.0026 inch)
Maximum	0.15mm (.0059 inch)
PISTON PIN	
Diameter	19.987-19.993mm (.7869-.7871 inch)
Interference Fit	0.010-0.027mm (.0004-.0012 inch)

LUBRICATION SYSTEM

OIL PUMP TYPE	Trochoid Gear
Regulating Pressure at 3,000 RPM	343-441 kPa (50-64 psi)
ROTOR CLEARANCE	
Inner Rotor Tooth Tip to Outer Rotor	0.02-0.16mm (.0008-.0063 inch)
Maximum	0.2mm (.0078 inch)
Outer Rotor to Body	0.09-0.18mm (.0035-.0071 inch)
Maximum	0.22mm (.0087 inch)
Side Clearance	0.03-0.11mm (.0012-.0043 inch)
OIL CAPACITY	
Total (Dry Engine)	3.6L (3.8 U.S. Quart)
Oil Pan	3.2L (3.4 U.S. Quart)
Oil Filter (Regular Size)	0.3L (.32 U.S. Quart)

CA13508-A

SPECIAL SERVICE TOOLS

Tool Number	Description
T74P-7137-K	Clutch Aligner
D88L-8000-A	Engine Support Fixture
T78P-3504-N	Seal Remover
T90P-6256-AH	Camshaft Seal Protector
T90P-6256-BH	Camshaft Seal Installer
T89P-6565-A	Valve Spring Compressor
T87C-6565-A	Valve Spring Compressor Pivot Bar
T90P-6565-AH	Valve Spring Compressor Brackets
T89P-6510-D	Valve Stem Seal Remover
T89P-6510-AH	Valve Stem Seal Installer
D81L-6002-C	Piston Ring Compressor
T64L-6011-EA	Cylinder Ridge Reamer
T87C-6019-A	Front Crankshaft Seal Installer
T87C-6701-A	Rear Crankshaft Seal Installer
T59L-1001-B	Impact Slide Hammer
D90P-6135-AH	Piston Pin Remover/Installer
T89P-6510-A	Valve Guide Remover
D83L-4201-A	Straight Edge
T73L-6011-A	Cylinder Hone Set
TOOL-4201-C	Dial Indicator
D81L-6002-D	Piston Ring Groove Cleaner

ROTUNDA EQUIPMENT

Model	Description
077-00043	Engine Lifting Crane
014-00705	Air Pressurization Kit