

SECTION 17

EEC-IV Monitor Intermittent Fault Diagnosis

Contents

Introduction	17-1
Diagnostic Flow Chart	17-3
Step 1: Visual Check, Vehicle Preparation	17-4
Step 2: Equipment Set-up	17-5
Step 3: Power and Ground Tests	17-6
Step 4: Symptom Analysis	17-10
Step 5: Road Test	17-11
Step 6: Analyzing Data	17-13
Appendix:	
Description and Installation of EEC-IV Monitor	17-17
Description and Installation of EEC-IV Recorder	17-22
Methods of EEC-IV Monitor Measurements	17-26

Introduction

All Engines

DEFINING INTERMITTENT DRIVEABILITY SYMPTOMS

The EEC-IV Monitor and the EEC-IV Monitor Recorder are useful tools for diagnosing intermittent driveability symptoms which are unable to be resolved through the diagnostics in Section 16 Pinpoint Testing. This section supports diagnostic procedures and data using the Monitor and Recorder in a symptom-oriented manner.

By definition an 'intermittent' is a randomly occurring drive symptom for which no hard codes (KOEO, KOER) are revealed by the SUPER STAR II tester. Often the Quick Test results in Pass Codes while the drive symptom still exists. Other results, such as Continuous Memory Codes, will also be used in this section.

Before proceeding with the following procedure, be sure that:

- Customary mechanical system tests and inspections reveal nothing. (Remember, mechanical component problems can make a good EEC system react abnormally.)
- Quick Test (Section 15) and associated Pinpoint Test diagnostics (Section 16) have been completed, but the symptom is still occurring.
- Review of Ford Technical Service Bulletins (TSB's) and inquiry into OASIS turns up no applicable articles.

PURPOSE OF THIS SECTION

The Monitor and Recorder function as a 'window' into the EEC system. Through this 'window' the user is able to view the same sensor and actuator values which the EEC processor uses to make decisions about engine performance. The Monitor displays these values for both static (Key Off, KOEO) and dynamic conditions (KOER). The advantage of the Recorder is the ability to take a 'snapshot' of selected EEC signals which can be stored and reviewed later.

NOTE: From here forward the EEC-IV Monitor and EEC-IV Monitor Recorder will be referred to as Monitor and Recorder, respectively.

Introduction

All Engines

A basic working knowledge of the EEC system is critical to efficient troubleshooting of the symptom. No diagnostic procedure can account for all the possibilities which can be encountered, therefore this diagnostic procedure only attempts to provide basic steps and methods for isolating possible causes.

The diagnostic procedure used in this section is a symptom-based approach for isolating the faulty system, circuit or sensor. Often a mechanical fault will cause a good EEC system to react abnormally. In those cases, the use of a Monitor with this diagnostic procedure will help to eliminate possible EEC faults and also locate mechanical faults.

REMEMBER

It is important that Quick Test (Section 15) has been performed before proceeding. Continuous Memory Codes must be recorded before disconnecting the EEC harness from the EEC processor to install the Monitor.


QUESTIONS/INFORMATION

In order for a vehicle to be correctly diagnosed it is important to obtain accurate information about the vehicle and the intermittent symptom. Consider the following points and questions:

- Get a full description of vehicle operating conditions when symptom occurs - details such as range of speed, engine hot or cold, accelerating or decelerating, heater or A/C on, engine noise, etc.
- Did the symptom occur gradually or all of sudden?
- Could it be related to a previous event - such as an accident or part replacement?
- What is the service history? Has it been serviced in the past in a way that might relate to the present symptom?
- Could the problem be related to customer: driving habits, improper maintenance or neglect, use of improper or poor fuels?

Diagnostic Flow Chart

All Engines



A14347-A

Visual Check, Vehicle Preparation

**All
Engines**

Step 1

NOTE: Be careful not to move anything while inspecting the vehicle. By doing so you could affect a possible fault and be unable to locate the original problem.

VISUAL CHECK

1. Inspect air cleaner and inlet ducting.
2. Check all engine vacuum hoses for damage, leaks, cracks, blockage, proper routing, etc.
3. Check EEC system wiring for proper connections, bent or broken pins, corrosion, loose wires, proper routing, etc.
4. Check the processor, sensors and actuators for physical damage.
5. Check engine coolant for proper level.
6. Check transmission fluid level and quality.
7. Make all necessary repairs before continuing.

VEHICLE PREPARATION

1. Perform all safety steps required to start and run vehicle tests - apply parking brake, place shift lever firmly into PARK position (NEUTRAL for Manual Transmission) and block drive wheels.
2. Turn off **ALL** electrical loads - radios, lights, A/C - heater fans, etc.
3. Start engine and run until at operating temperature.
4. Turn off engine and proceed with **Equipment Set-up**.

Equipment Set-up**All
Engines****Step 2****CAUTION**

The vehicle ignition power switch must be turned off (Key Off) before disconnecting the EEC harness cable from the EEC processor.

EQUIPMENT SET-UP

1. Check for Continuous Memory Codes. These codes must be recorded before disconnecting the EEC harness, otherwise they will be erased.
2. Install Monitor — refer to Installation procedure in the Appendix.
3. Select proper Monitor overlay card for the appropriate engine. See Chart Below.
4. If a Recorder is available, do not install it at this time.

SPECIAL NOTES

- The Appendix contains necessary information about installation and use of the Monitor and Recorder. Also included in the Appendix are descriptions of different methods and Auxiliary equipment used in Monitor measurements.
- If for some reason the correct overlay card is not available for the particular engine, the Monitor may still be used with a few limitations. In this situation, no overlay card is used and the technician must rely on the pin number label on PIN SELECTOR A and the Light Array to identify the EEC signals. The Monitor can only be used in the Manual Mode (DCV, OHMS). Do not substitute an incorrect overlay because the readings in the AUTO mode will not be correct and the signal labels on the overlay may also be different.

OVERLAY USAGE CHART

ENGINE	TRANS	OVERLAY NUMBER
1.6L Naturally	MTX	46
Aspirated	ATX	46
1.6L Turbo	MTX	47

Power and Ground Tests**All
Engines****Step 3****STRATEGY FOR LOCATING POWER AND GROUND FAULTS**

If the value of a ground or power circuit is out of range or a signal is suspected as being faulty, then use the following methods to determine the fault. Refer to the Appendix: Methods of EEC-IV Monitor Measurements.

- Inspect circuit wires for visible breaks or shorts, loose connectors, bent or pushed out connector pins or corrosion.
- Test vehicle battery for low voltage and current.
- Perform Monitor Wiggle Testing. An audible beep will sound if an intermittent short or open is present.
- Perform Click Testing for those signals which activate relays or solenoids. Using the switch box in the selector pin jacks allows relays and solenoids to activate.

Power and Ground Tests

All Engines

Step 3

TEST STEP		RESULT	ACTION TO TAKE
PG0	POWER TEST		
<ul style="list-style-type: none"> • Key off. • Monitor power ON. • Check the green LED KAPWR. • Is the LED on? 		Yes No	GO to PG1 . SERVICE the KAPWR circuit to the battery.
PG1	MONITOR LED TEST		
<ul style="list-style-type: none"> • Key off. • Monitor power ON. • Place the lamp test switch to the test position. • Check all LEDS on the Monitor including the 6 yellow LEDS in the Remote Display. • Did all the LEDS light and did the audible beep sound? 		Yes No	GO to PG2 . The Monitor is damaged and requires service.
PG2	MONITOR REMOTE DISPLAY TEST		
<ul style="list-style-type: none"> • Key off. • Monitor power ON. • Depress the Remote Display Button. • Does the Display indicate "1888"? <p>NOTE: Temperature extremes above 158°F (70°C) will result in a black display and cold temperature extremes will cause the display to run slow. Display will return to normal during normal ambient temperatures.</p>		Yes No	GO to PG3 . The Monitor is damaged and requires service.

Power and Ground Tests

**All
Engines**

Step 3

TEST STEP		RESULT	ACTION TO TAKE																		
PG3	POWER VOLTAGE LEVEL CHECKS																				
<ul style="list-style-type: none">• Key on, engine off.• Place Pin Selector A to Pin Selector B position.• Verify voltages in the following Chart: <table><tr><th colspan="3">POWER</th></tr><tr><th>Signal</th><th>Value</th><th>Possible Fault</th></tr><tr><td>KAPWR/KAM</td><td>>10.5V</td><td>EEC Harness, Battery</td></tr><tr><td>VPWR</td><td>>10.5V</td><td>EEC Harness, Power Relay, Battery, Ignition Switch, Battery Cables</td></tr><tr><td>KAPWR</td><td>>10.5V</td><td>EEC Harness, Battery, Ignition Switch</td></tr><tr><td>VREF</td><td>4.5V – 5.5V</td><td>EEC Harness (EEC Module)</td></tr></table> <ul style="list-style-type: none">• Did all the voltage levels correspond to the Chart?		POWER			Signal	Value	Possible Fault	KAPWR/KAM	>10.5V	EEC Harness, Battery	VPWR	>10.5V	EEC Harness, Power Relay, Battery, Ignition Switch, Battery Cables	KAPWR	>10.5V	EEC Harness, Battery, Ignition Switch	VREF	4.5V – 5.5V	EEC Harness (EEC Module)	<div>Yes</div> <div>No</div>	<div>GO to PG4 .</div> <div>SERVICE the circuit(s) at fault.</div>
POWER																					
Signal	Value	Possible Fault																			
KAPWR/KAM	>10.5V	EEC Harness, Battery																			
VPWR	>10.5V	EEC Harness, Power Relay, Battery, Ignition Switch, Battery Cables																			
KAPWR	>10.5V	EEC Harness, Battery, Ignition Switch																			
VREF	4.5V – 5.5V	EEC Harness (EEC Module)																			
PG4	GROUND VOLTAGE LEVEL CHECKS																				
<ul style="list-style-type: none">• Key on, engine off.• Monitor power ON.• Verify voltages in the Chart below: <table><tr><th colspan="3">GROUND</th></tr><tr><th>Signal</th><th>Value</th><th>Application</th></tr><tr><td>PWRGND</td><td>0 + .5V</td><td>All Engines</td></tr><tr><td>SIGRTN</td><td>0 + .5V</td><td>All Engines</td></tr><tr><td>MT/AT(1V)</td><td>0 + .5V</td><td>All Engines</td></tr></table> <ul style="list-style-type: none">• Do all the voltage levels correspond to the chart?		GROUND			Signal	Value	Application	PWRGND	0 + .5V	All Engines	SIGRTN	0 + .5V	All Engines	MT/AT(1V)	0 + .5V	All Engines	<div>Yes</div> <div>No</div>	<div>GO to PG5 .</div> <div>SERVICE the circuit(s) at fault.</div>			
GROUND																					
Signal	Value	Application																			
PWRGND	0 + .5V	All Engines																			
SIGRTN	0 + .5V	All Engines																			
MT/AT(1V)	0 + .5V	All Engines																			

Power and Ground Tests

**All
Engines**

Step 3

TEST STEP		RESULT	ACTION TO TAKE												
PG5	OTHER POWER CHECKS														
<ul style="list-style-type: none">• Key on, engine off.• Monitor power ON.• Verify voltages in the Chart below: <table><tr><th colspan="3">POWER</th></tr><tr><th>Signal</th><th>Value</th><th>Application</th></tr><tr><td>VMREF</td><td>7 – 9V</td><td>1.6L (All)</td></tr><tr><td>Start(1C)</td><td>10 – 14V Cranking</td><td>All Engines</td></tr></table> <ul style="list-style-type: none">• Do the voltages correspond to the Chart?		POWER			Signal	Value	Application	VMREF	7 – 9V	1.6L (All)	Start(1C)	10 – 14V Cranking	All Engines	<div>Yes</div> <div>No</div>	<div>GO to Step 4, EEC-IV Monitor Symptom Charts.</div> <div>SERVICE the circuit(s) at fault.</div>
POWER															
Signal	Value	Application													
VMREF	7 – 9V	1.6L (All)													
Start(1C)	10 – 14V Cranking	All Engines													

Symptom Analysis

All Engines

Step 4

PURPOSE OF THIS STEP

When an intermittent symptom occurs, get a full description of the symptom and the driving mode when it happens.

FINDING PROBABLE CAUSES

- Refer to Diagnostic Routines (Section 2) for a list of all Systems and components that may cause the symptom.
- Check each System (Electronic and Mechanical) listed in Diagnostic Routines.
- The EEC portion of each Routine lists components most likely to cause the symptom. These components should be checked first.
- Refer to the EEC Graphs and Charts and Diagnostic Reference Value in this section.
- **REMEMBER:** The conditions and driving mode can provide clues to the cause of the symptom.

Example: A hard start symptom with engine cold could indicate an ECT sensor malfunction.

CHECK THE BASICS:

- Always make sure things like fluid levels, maintenance schedules, and proper vehicle use are OK. Old, clogged fuel filters can cause intermittent problems, so can low coolant levels and poor oil quality.
- Good power and ground connections, and good harness condition are **VERY** important. Poor grounds and powers (to injectors, for example) can cause intermittent symptoms.

Road Test**All
Engines****Step 5****RE-CREATING THE SYMPTOM**

In order to diagnose an intermittent symptom, one must re-create the symptom and collect information on how the EEC system is sensing and reacting. After visual and non-EEC checks are completed and satisfied, the EEC portion is diagnosed. Through the use of Monitor and Recorder these signal lines can be inspected for shorts, opens, component failures or erratic behavior. In addition, the information received from the Monitor and Recorder can reveal the presence of mechanical problems.

Select the EEC components in the Diagnostic Routines to troubleshoot the system. These components are listed in a suggested order to represent the most likely components to cause each unique symptom.

OPTIONAL

If a Recorder unit is available, install it at this time — refer to Installation Procedure in the Appendix.

ROAD TEST SET-UP

1. Place Monitor (Recorder also, if installed) in convenient location inside the vehicle. Secure cables that may be attached from engine compartment to the Monitor or Recorder inside the vehicle.
2. Check to see if the proper overlay card is inserted on Monitor. Refer to note in **Step 2** if correct overlay is not available.
3. Copy the list of EEC sensors and actuators in order given by Diagnostic Routines. These signals will be monitored during the road test.
4. If a Recorder is used, then select the first 8 signals listed in the Diagnostic Routines for Channels 1 to 8. Connect the jumpers from the I/O jacks to the appropriate channels. Refer to Appendix for set-up, if needed.
5. Select the proper **Diagnostic Reference Value Sheet** in Appendix. This sheet lists EEC sensor and actuator values at various operating conditions. The values given on these sheets are for reference only.
6. In order for a road test to be performed it is required that another person accompany the driver. This is a safety issue because the driver alone should not be diverting his attention to operation of this test equipment. The accompanying person can select signals, observe changes and record notes.

USE OF AUXILIARY EQUIPMENT INPUTS

Some useful signals which are listed in the Diagnostic Routines may require the use of auxiliary equipment. These devices can be inserted into the AUX input jacks of the Monitor or the ADAPT 1/ADAPT 2 input jacks of the Recorder. Listed are two types of peripherals and examples of the signals they receive.

Multi-Point Auxiliary Adapter — A/C, Fuel Pump

Electronic Fuel Pressure/Vacuum Adapter — Fuel Pressure, Vacuum

Road Test**All
Engines****Step 5****ROAD TEST REMINDERS**

The purpose of the road test is to re-create the problem symptom by duplicating the conditions that caused it to occur.

Alternatives. In some cases it may not be necessary or desirable to perform an actual road test. The symptom may occur at starting, idle or high RPM idle conditions. If this situation applies proceed with the **Road Test Procedure** by using the operating condition that applies to your situation.

Legality/Liability. The **Road Test Procedure** is a suggested and optional part of this section. The liability of this operation is left to the individual who chooses to use it.

Safety. It is important that the road test is performed with safety issues in mind. Use the vehicle seat belts and operate the vehicle in a safe manner.

ROAD TEST OBSERVATIONS

During the road test various EEC signals are chosen and their values shown. In addition, there is other important information that can be viewed during the road test.

EEC Values. Compare road test values at various operating conditions with those listed in the **Diagnostic Reference Value Sheets**. Refer to **Appendix: EEC Graphs and Charts** for further detail.

Monitor Lights. Observation of the Monitor lights gives quick information about the condition of many EEC signals. Observation of these lights can quickly reveal the general status of many signals and tell whether a solenoid or switch is activated. Optional signals are identified in yellow labels.

Wiggle Testing. By using the Monitor Wiggle test in KOER, often an intermittent device or wire will trigger the alarm. The DCV Wiggle mode in particular is very sensitive to sudden, erratic changes in an EEC harness or component.

ROAD TEST PROCEDURE

1. Using the appropriate routine, select the first listed EEC device on Monitor PIN SELECTOR A.
2. Turn on Monitor and Recorder if used. Start and drive vehicle.
3. If Recorder is installed put FUNCTION switch in RECORD mode and press START RECORD button.
4. Drive vehicle to create conditions so that the symptom occurs.
5. When the symptom occurs, the accompanying passenger should observe changes in selected EEC signal. Information should be recorded onto paper with other specific notes about the symptom, device, or operating conditions. If the Recorder is used, the CAPTURE button should be pressed.
6. If the Monitor is used without the Recorder, the next EEC signal on the routine can be selected on PIN SELECTOR A. The drive symptom should then be re-created and recorded as in the previous step. This step is to be re-created until the cause of the problem is found or enough data is collected to return and analyze.
7. If the Recorder is used, the accompanying passenger may wish to write down the data from the Recorder channels onto paper. The drive symptom can be created and recorded again for confirmation. Otherwise, the road test is completed and you can return to analyze the results.

Analyzing Data

All Engines

Step 6

ANALYZING DATA

Once the road test is completed, the results need to be analyzed to find and repair the exact fault which caused the symptom. The notes taken during the road test can now be analyzed, discussed and compared with Appendix data.

INSIGHTS FROM THE RECORDER

The use of the Recorder greatly enhances the view of the EEC operation during the presence of the symptom and allows a systems approach to the problem. By setting the FUNCTION switch to PLAYBACK mode and inspecting the recorded channels, you can begin to evaluate the results.

Look for abnormal behavior or values that are clearly incorrect. Inspect the signals for abrupt or unexpected changes. For example, during a steady cruise most of the sensor values should be relatively stable. Sensors such as TP and VAF changing abruptly when the vehicle was travelling at a constant speed are clues.

Look for agreement in related signals. For example, if TP is changed during a gentle acceleration a corresponding change should occur in VAF. Compare signals by selecting different channels at a certain time range. The PLAYBACK METERS can also be viewed for quick comparisons.

Make sure the signals act in proper sequence. An increase in RPM after the TP is increased is valid. However if the RPM increases without a TP change then a problem exists.

ANALYZING METHODS

Use any of the following methods to further troubleshoot a suspected EEC signal. Some methods are unique to a certain type of EEC device. Follow the given strategy listed for each unique device on the successive pages. Refer to the Appendix for greater detail — **Methods of EEC-IV Monitor Measurement.**

- Change Condition to Cause Response by Input
- Change Input and Verify Output Response
- Click Testing (Solenoids/Relays)
- Coil Resistance (Solenoids/Relays)
- EEC Input Check
- Harness Continuity
- Harness Shorts
- Output State Check (Solenoids/Relays)
- Wiggle Testing (DCV or OHMS)

Analyzing Data

All Engines


Step 6

ANALYZING DATA: Suggested Strategies for Sensors/Inputs

2 Wire Sensors

Device:

ECT
VAT


Typical Schematic:

Strategy:

Check Cold Value
Check Warm Value
DCV Wiggle Testing
EEC Input Check
Harness Shorts
Harness Continuity

3 Wire Sensors

Device:

EVP
TP
VAF

Typical Schematic:


A14089-A


Strategy:

Check Value
Change Condition
DCV Wiggle Testing
EEC Input Check
Harness Shorts
Harness Continuity

Switches

Device:

ACS	FAN	MLP
BOO	PSPS	MLPOD
NGS/CES	BLMT	MLPL
CTS	DEF	MLPD
MMS	HDLT	
DRL	WOT	
IDL	VST	

Typical Schematic:


A14091-B

Strategy:

Check Value
Change Condition
DCV Wiggle Testing
Harness Shorts
Harness Continuity

Analyzing Data

**All
Engines**


Step 6

Other Input Signals

Device:

BP	PIP	STI
CID1	DSS	VMREF
CID2	STI	CIDREF
EGO	VSS+	TCSRET
CPS	VSSW	DSS
KS	MT/AT	CAN/CAL
IDM	TCS	

Typical Schematic:



A14092-A

Strategy:

Check Value
Change Condition
DCV Wiggle Testing
or
Ohms Wiggle Testing
EEC Input Check
Harness Shorts
Harness Continuity


ANALYZING DATA: Suggested Strategies for Actuators/Outputs

Solenoids/Relays

Device:

WAC	SS1
PRC	SS2
INJ	SS3
CANP	CCC
ISC	FP
HSIA	BOOST
EGRC	
EGRV	
HSF	

Typical Schematic:



A14093-A

Strategy:


Check Value
Change Input
Click Testing
DCV Wiggle Testing
Coil Resistance
Output State Check
Harness Shorts
Harness Continuity

Other Output Signals

Device:

SML
MIL
STO
SPOUT
MSL
KCU
OBI

Typical Schematic:



A14094-A

Strategy:

Check Value
Change Input
Ohm Wiggle Testing
Harness Shorts
Harness Continuity

Analyzing Data**All
Engines****Step 6****OPTIONAL DIAGNOSTIC TOOLS**

By using the suggested strategies for the "suspect" EEC components the source of the fault can be found. If after following the given methods a fault is not found then a few options still remain.

Follow-up Diagnosis. The Monitor and Recorder can be used to troubleshoot EEC signals other than those listed in the chosen **Symptom Chart in Section 2**. By conducting a thorough investigation of all the EEC signals, the source of the problem can likely be found. Available for auxiliary (AUX) inputs are two items **Multipoint Auxiliary Adapter (#007-00023)** and the **Electronic Fuel Pressure/Vacuum Adapter (#007-00022)**.

Other Diagnostic Tools. If needed, there are other specialized tools that could aid in troubleshooting.

One useful tool is the **Fuel Testing Kit (#113-00004)** used in checking the presence of contaminated fuel.

Section 2. Diagnostic Routines, Section 2 of this volume, lists various symptoms and references possible systems and components. Also referenced in this location are other volumes and group numbers.

VERIFICATION

After the vehicle fault has been located and repaired, a verification test needs to be performed. This may require a road test to verify that the symptom is no longer present. It is also important to remember that if any Continuous Memory Codes were present before the symptom was repaired, those codes must be cleared. Refer to **Section 15 Appendix — Erasing Memory Codes**.

APPENDIX: Description and Installation of EEC-IV Monitor

EEC-IV MONITOR INSTALLATION

1. The vehicle ignition power switch must be turned off (Key Off) before disconnecting the EEC harness cable from the EEC processor and installing the Monitor. Remember to record any Continuous Memory Codes obtained during Quick Test; removal of the harness results in loss of Keep Alive Memory Power (KAPWR) and will result in loss of any codes.
2. Remove the lid from the Monitor and ensure that the POWER switch is in the OFF position.
3. Disconnect the EEC harness cable from the EEC processor.
4. Inspect the connector for loose or damaged pins, corrosion or loose wires.
5. Attach the appropriate EEC adapter cable to the EEC processor. Refer to Figure 1.
6. Attach Monitor connector to the EEC adapter cable and tighten the bolt on the connector with the 10mm socket until snug. Do not overtighten. Refer to **Figure 1**. Attach the vehicle harness to the adapter cable.




Figure 1

7. Select correct overlay card for the Monitor according to label on the overlay envelopes. Install on Monitor front panel.
8. Position the Monitor where it can be conveniently viewed and operated. If the Monitor is to be operated in the engine compartment, be sure to route the connecting cable away from moving parts, ignition wires, coil and door or hood ornaments. If the Monitor is to be operated in the passenger compartment, it may be placed on the seat or suspended from the instrument panel.
9. To suspend the Monitor from the instrument panel use the straps supplied with the Monitor and fasten the hooks into the windshield defroster vents.
10. Place the remote display in a convenient viewing position — either attached to the top or bottom of the Monitor, passenger visor, or edge of the dashboard.
11. Check to see that all electrical devices are off — items such as radio, lights, power windows, A/C and others.

APPENDIX: Description and Installation of EEC-IV Monitor

EEC-IV MONITOR — WHAT IS IT?

The EEC-IV Monitor is an electronic tool which measures the operation of the electronic sensors and actuators of the EEC system. Its main purpose is to let the technician 'see' the same information that the processor receives and observe how the processor reacts to the information. The Monitor has other capabilities such as a built-in wiggle test used to locate intermittents in wiring, connections and other EEC components.

WHY IS IT USEFUL?

The Monitor is useful in identifying hard to diagnose vehicle problems. Many vehicle failures are hard faults and pinpoint diagnostics (Section 16) make it relatively easy to find the damaged part and fix the problem. But for problems that are intermittent and do not generate codes, the Monitor enables the technician to view the sensor and actuator signals so that judgements can be made by comparing the signals to normal operating conditions.

The Monitor readings are also helpful in locating non-electronic failures. By verifying that the electronics are not at fault, unnecessary replacement of a good component can be avoided. The technician can then investigate likely non-electronic systems capable of causing the same symptoms. Using the Monitor to read the electronic sensors associated with a mechanical system provides a check of the non-EEC system.

OVERALL DESCRIPTION OF MONITOR (Figure 2)

1. **The Main Unit.** This is the brains of the EEC-IV Monitor. It contains all the switches, buttons and lights that enable the technician to perform diagnostic tests.
2. **Remote Display.** A LCD readout is used to display all Monitor measurements. This display is housed in a small box which is detached from the Main Unit. Viewing is easy and convenient because the display may be mounted in various locations.
3. **T-Connector and Harness.** The T-connector is a special plug which is attached between the vehicle harness connector and the processor. The Monitor receives power through this connection as well as access to all electrical signals entering and leaving the processor.
4. **Overlays.** This item is a plastic card which is installed on the Monitor to program it for use. Each engine family has a unique overlay associated with it. The sensor signals are listed in the inner blue circle around PIN SELECTOR A; the outer red circle lists the output signals. In addition, they list only those signals applicable to the specific vehicle being tested.
5. **Switch Box.** The switch box is a small device which can be plugged into the Selector Pin and REFERENCE PIN JACKS located on the lower left corner of the Monitor. It is useful for testing solenoid and relay operations.
6. **Straps.** These straps snap to the Monitor main unit case and are used to hold the Main Unit in a convenient place for on-the-road testing.

APPENDIX: Description and Installation of EEC-IV Monitor




Figure 2

AUXILIARY EQUIPMENT FOR THE MONITOR

The Monitor, in addition to all of its useful testing, can be used with some very helpful peripheral tools. The **Electronic Fuel Pressure/Vacuum Adapter (#007-00022)** can be used in the AUX input jacks to measure fuel pressure or vacuum. The **Multipoint Auxiliary Adapter (#007-00023)** or "Octopus" is also a device which inserts into the AUX input jacks. It can be used to measure many different non-EEC electrical signals such as fuel pump, A/C and battery. And of course the most useful Auxiliary Equipment tool used in conjunction with the Monitor is the EEC-IV Monitor Recorder, which is described later in this section.

APPENDIX: Description and Installation of EEC-IV Monitor

MONITOR DESCRIPTION (Figure 3)

1. **POWER.** Monitor ON/OFF switch.
2. **LIGHT TEST.** NORM is operational mode; TEST modes activates all lights and beeps.
3. **AIM.** Audible Intermittent Monitor — 3 positions: OFF, KOEO beeps when STO is at ground and KOER initiates Self-Test and also beeps when STO is at ground.
4. **EGO SENSORS.** 3 positions: NORM, RICH applies rich signal to EEC processor and LEAN applies lean signal to EEC processor. Single EGO engine uses only #1 switch.
5. **TIMING.** Selects COMP (computed or normal) mode which reads spark advance from the EEC processor or DIST which allows the Monitor to be calibrated to base timing.
6. **BASE TIMING.** Calibrates base timing when TIMING switch is in DIST mode.
7. **PIN SELECTOR A.** Rotary dial allows selection of EEC signals.
8. **PIN TYPE.** Selects between 2 modes for PIN SELECTOR A — 'Blue' (inner) sensors/inputs or 'Red' (outer) actuators/outputs.
9. **PIN SELECTOR B.** Rotary dial allows selection of EEC power and STI signals.
10. **SPEED.** Selects between MPH and KPH readings for vehicle speed signals.
11. **RPM.** Selects between NORM and x10 scale readings for ignition signals.
12. **FUNCTION.** 3 positions: AUTO measurements with varied units, DCV readings in DCV only and uses REFERENCE PIN dial and OHMS resistance readings only and uses REFERENCE PIN dial also. DCV and OHMS will light MANUAL TEST lamp.
13. **REFERENCE PIN.** Selects ground or voltage when FUNCTION is in DCV or OHMS.
14. **OHMS RANGE.** Switches between 2K and 200K range readings for OHMS mode.
15. **WIGGLE TEST.** RESET button resets Manual mode wiggle test, turns off beeper or light if either is on.
16. **EGRV.** Activates EGR vent solenoid when depressed (special applications).
17. **EGRC.** Activates EGR control solenoid when depressed (special applications).

APPENDIX: Description and Installation of EEC-IV Monitor

18. **PUSH TO TEST.** (Located on Remote Display) Local test turns on all digits in readout "1888".
19. **EEC POWER/SIGNAL STATUS INDICATORS.** Grouped into 3 categories: Power, Sensors and Actuators. Lights show status of signals.
20. **SELECTOR PIN JACKS.** Top (red) jack probes PIN SELECTOR A/B signal; bottom (black) jack probes REFERENCE PIN signal.
21. **AUX INPUT.** Jacks used to measure external signals.
22. **AUX POWER.** Jack supplies power for Aux input device.
23. **PORT A/PORT B.** Enables EEC-IV Monitor Recorder to be connected.
24. **METER FUNCTION.** Light on identifies type of measurement units used.
25. **MANUAL TEST.** Light blinks when FUNCTION switch is in Manual DCV or OHMS, otherwise light remains off.
26. **STAR TESTER CONNECTION.** Enables hook-up of SUPER STAR II without using Self-Test connector.




Figure 3

APPENDIX: Description and Installation of EEC-IV Recorder

EEC-IV RECORDER INSTALLATION

1. Monitor must be installed first in order to use the Recorder. Make sure that the correct overlay card is installed.
2. Place the Recorder in an appropriate location near the Monitor. Check to ensure the Recorder power switch is OFF. The lid of the Recorder may be removed if so desired.
3. Install PORT A cable of the Recorder into PORT A connector on the Monitor; install PORT B cable in a similar manner. See that the cables are properly oriented before insertion and are firmly seated. See **Figure 4**.




Figure 4




Figure 5

4. As a final step, install the white overlay card around the eight playback buttons. This card will be used later to keep track of the signal names of the recorded channels. Refer to **Figure 5**.

APPENDIX: Description and Installation of EEC-IV Recorder

EEC-IV RECORDER — WHAT IS IT?

Basically the Recorder works the same as an audio cassette recorder except that up to eight different channels can be recorded at the same time and the recording is stored in an electronic memory instead of on a tape cassette.

The Recorder is part of the EEC-IV Monitor Diagnostic System. When attached to the Monitor, the Recorder can monitor to the same sensor and actuator signals that the EEC processor receives.

WHY IS IT USEFUL?

The Recorder is useful in helping to isolate intermittents and repeatable driveability problems. It does this by recording selected signals during a period of abnormal vehicle behavior. The information is stored and can be replayed to determine which devices or systems are malfunctioning. The Recorder can also be triggered automatically to record from the Monitor Wiggle Test.

OVERALL DESCRIPTION OF THE RECORDER (Figure 6)

1. **Main Unit.** This contains all the circuitry necessary for recording operations. It must be connected to an EEC-IV Monitor. All aspects of signal recording and playback are controlled by the front panel switches and buttons.
2. **Selection Cable.** The bundle of jumper leads used to connect the eight recording channel inputs of the Recorder to any of the pins of the EEC connector.
3. **Overlay Card.** The white card fits around the playback buttons. The user marks the signal names being recorded next to the recording channel number.
4. **Marking Pen.** This special felt-tip pen is used to mark the overlay card. The markings can easily be erased with a moist tissue or cloth.




Figure 6

APPENDIX: Description and Installation of EEC-IV Recorder

AUXILIARY EQUIPMENT

The Recorder allows external Auxiliary Equipment to be used with it. The Recorder allows up to two auxiliary inputs, of which the **Electronic Fuel Pressure/Vacuum Adapter** and the **Multipoint Auxiliary Adapter** inputs can be used. For outputs, the Recorder supplies PLAYBACK CHANNELS A AND B jacks for use with a DVOM or a graphic recording device. Finally, the Recorder provides an input jack on its lower left side which allow a remote capture activating device to be used.

RECORDER DESCRIPTION (Figure 7)

1. **ON/OFF.** Recorder power.
2. **MODE.** Select between NORMAL and WIGGLE modes for initiating capture of recorded signals.
3. **CAPTURE.** When activated, the recorder saves the previous 30 second period and continues to record the future 20 second period. A tone will sound and light will flash while recording.
4. **START RECORD.** Operates in FUNCTION RECORD mode only. Will initiate continuous recording of selected channels. A tone will sound.
5. **FUNCTION.** Selects between PLAYBACK and RECORD modes.
6. **PLAYBACK METER.** Shows dynamic reading from 0-20 volts on respective channels. Output jacks are available for remote readings.
7. **B SELECT.** When pressed before one of channels 1 thru 8, selects B channel for PLAYBACK mode.
8. **CHANNEL SELECT.** Choice of eight channels to be displayed in PLAYBACK mode.
9. **PLAYBACK DIRECTION.** Choice of REVERSE or FORWARD directions (range is -30 to 19.9 seconds) and choice of NORM (continuous) or STEP (.1 second increments).
10. **TIME.** Display expressed in seconds and designated '+' or '-' for CHANNEL A.
11. **CHANNEL INDICATOR.** Displays CHANNEL A on top; CHANNEL B on bottom.
12. **ADAPTER INPUTS.** Special optional inputs used for CHANNELS 1 and 2 only.
13. **CHANNEL INPUTS.** Channels 1 thru 8 selected with switches for optional inputs with non-DCV units.
14. **CHANNEL I/O.** Jacks for 60 channels from EEC processor which are able to be jumpered to Channels 1 thru 8.
15. **REMOTE CAPTURE INPUT.** Allows optional input to activate capture via remote device.

APPENDIX: Description and Installation of EEC-IV Recorder




Figure 7

APPENDIX: Methods of EEC-IV Monitor Measurements

MONITOR LIGHT INDICATOR VALUES

The light or LED array on the upper left side of the Monitor displays the status of many key EEC signals. By observing these lights, one can easily gain information about the condition of dynamic EEC signals.

Preliminary: Light Test. Prior to operation of the Monitor it is a good practice to verify that all the lights are functional. Turn on the Monitor. When the LIGHT TEST switch is set to TEST mode all the lights (or LEDs) should light and the beeper sound. The red EGO light will be dim. Return the switch back to NORM when the test is completed.

Power Indicators. The top group of indicators display power and STI signals. When the appropriate voltage is present the light will be lit. For example, at Key On, the KEYPWR (optional), VREF and VPWR lights should all be visible. The STI light is on when the signal is 0 volts (Key off) and off when 5v is present at Key On.

Input Signal Indicators. The second group of indicators are selected input signals which are lit when their voltage is above 2.5V; off when below 2.5V. There is one exception to this manner of operation—the EGO sensor. The knock sensor lights when the signal is above 1V. The EGO has two lights; the green lights for lean (below +.45V) and the red for rich (above +.45V). During certain engine run conditions the EGO sensor can be seen switching back and forth between green (lean) and red (rich).

Output Signal Indicators. The bottom group of indicators are output signals such as solenoids, relays and injectors. These signals are lit when their value is below 6V and off when above 6V. For example, this means that most solenoids will be lit when they are activated. Injectors will be blinking on and off in proportion to their on times.

Meter Function Indicators. The far right column of indicators display the type of units for the value on the remote display unit. During Manual DCV or OHMS the MANUAL TEST indicator will blink and the appropriate DCV or OHMS indicator will light. In AUTO Mode the correct unit indicator will light automatically. Listed in the following chart are the types of AUTO units which apply for the various EEC signals.

AUTO MODE UNITS	
Signal	Units
IDM, TACH	RPM
ISC	Duty Cycle %
Injectors	MSEC
All Others	DCV

CA14095-A

APPENDIX: Methods of EEC-IV Monitor Measurements

AUTO MEASUREMENTS

AUX — Multipoint Auxiliary Adapter (Octopus)

1. KOEO/KOER.
2. Select PIN SELECTOR A AUX (red).
3. Insert jumper from device into AUX input jack.
4. Read value in DCV (DCV light on).

Change Condition to Cause Response by Input

1. KOEO or KOER.
2. Select sensor on PIN SELECTOR A.
3. Create condition or change in condition.
4. Observe change in sensor value; verify with **EEC Graphs and Charts**.
5. Examples: Move throttle, observe TP increase.
Warm-up engine, observe ECT decrease.
Press brake pedal, observe BOO light.

Change Input and Verify Output Response

1. KOEO or KOER.
2. Select actuator on PIN SELECTOR A.
3. Create change for input device with switchbox or vehicle operation.
4. Observe change (response) in actuator signal, observe light.
5. Examples: Increase throttle (TP), observe SPOUT increase. Move EGO switch to LEAN, observe SPOUT increase. Turn on A/C at WOT, observe WAC light on and grounded.

Check Value

1. KOEO/KOER.
2. Select signal from PIN SELECTOR A or B.
3. Various units used, refer to METER FUNCTION light.

Click-Testing (Relays/Solenoids)

1. KOEO only.
2. Can also be done in Manual DCV Function mode.
3. Select relay or solenoid signal on PIN SELECTOR A and correct ground on REFERENCE PIN selector.
4. Insert Switchbox into SELECTOR PIN jacks.
5. Push small red button to turn on relay or solenoid.
6. Listen for "click" of device turning on, observe signal light turn on and device energizing.

APPENDIX: Methods of EEC-IV Monitor Measurements

EEC Input Check (STO)

1. KOEO.
2. Select sensor from PIN SELECTOR A.
3. Set REFERENCE PIN selector to SIG RTN.
4. Insert switchbox into SELECTOR PIN jacks.
5. Move AIM switch to KEY ON ENG OFF position.
6. Push small red button on switch box and observe STO light turn on and beeper sound as long as button is pressed.
7. Return AIM switch to OFF position.

Output State Check (Solenoids/Relays)

1. KOEO.
2. Move AIM switch to KEY ON ENG ON position and wait for output codes (beeps) to end.
3. Completely depress and release throttle — observe signal light turn on.
4. Completely depress and release throttle — light should turn off.
5. Return AIM switch to OFF position.

MANUAL OHMS MEASUREMENT

Electronic Fuel Pressure/Vacuum Adapter (EFPVA)

1. KOEO/KOER.
2. Select AUX on PIN SELECTOR A (red).
3. Select Manual OHMS switch and 200K OHMS RANGE switch.
4. Insert device into AUX input jacks.
5. Attach opposite end of adapter to appropriate Schrader valve (fuel pressure) or vacuum valve (vacuum pressure).
6. On EFPVA device set switch for ENGLISH (fuel press units — psi, vacuum units — in-Hg) or METRIC (kPa).
7. Read units according to switch setting and instructions printed on back of EFPVA device.

APPENDIX: Methods of EEC-IV Monitor Measurements

External Ohms

1. Key Off.
2. Select EXT on PIN SELECTOR A.
3. Select correct ground on REFERENCE PIN selector.
4. Select OHMS RANGE switch.
5. Verify that resistance to be measured is not connected to vehicle.
6. Connect jumper wires from SELECTOR PIN jacks to device to be measured.
7. Read value of resistance.

Harness Continuity

1. Key Off.
2. Select signal from PIN SELECTOR A.
3. Disconnect sensor/actuator where signal is to be checked.
4. Connect jumper wire from REFERENCE PIN jack (black) to signal pin on harness to be tested.
5. Check for continuity — 0 Ohms.

Harness Shorts

1. Key Off.
2. Select signal from PIN SELECTOR A.
3. Set OHMS RANGE switch to 200K.
4. Disconnect sensor/actuator to be tested.
5. Disconnect EEC Processor
6. Select various power or ground signals from REFERENCE PIN selector for which device is being tested against. Example: VREF, SIG RTN, PWR GND.
7. Read resistance: 0 or low indicates a short, 10K or higher — no short.

Ohms Value (Coil Resistance)

1. Key Off only.
2. Select signal from PIN SELECTOR A and PIN TYPE.
3. Select correct ground from REFERENCE PIN selector.
4. Select OHMS RANGE switch.
5. Wiggle Test will light and sound; press WIGGLE TEST RESET button.
6. MANUAL TEST light should be blinking; value in Ohms units.

APPENDIX: Methods of EEC-IV Monitor Measurements

OHMS Wiggle Testing

1. Key Off only.
2. Select signal from PIN SELECTOR A and PIN TYPE.
3. Select correct ground from REFERENCE PIN selector.
4. Tap components, flex harness and connectors.
5. WIGGLE TEST lamp and beeper will activate when change sensed.
6. OHMS Wiggle is less sensitive than the DCV Wiggle test.
7. Criteria for using OHMS Wiggle as opposed to DCV Wiggle:
 - a. All sensors which do not use DCV units in AUTO mode
 - b. Example: PIP, SPOUT, CPS

Power/Ground Harness Continuity

1. Key Off.
2. Select EXT on PIN SELECTOR A.
3. Select desired power/ground signal on REFERENCE PIN selector.
4. Disconnect sensor/actuator where power/ground signal is to be checked.
5. Connect jumper wire from SELECTOR PIN jack (red) to ground/power signal pin on harness to be tested.
6. Check for continuity — 0 Ohms.

MANUAL DCV MEASUREMENTS

DCV Wiggle Testing

1. KOEO/KOER.
2. Select signal from PIN SELECTOR A or B.
3. Select correct ground from REFERENCE PIN selector.
4. Tap component, flex harness and connectors.
5. WIGGLE TEST lamp and beeper will activate when change sensed.
6. DCV Wiggle is more sensitive and commonly used than the OHMS Wiggle Test.
7. Criteria for using DCV Wiggle as opposed to OHMS Wiggle:
 - a. All actuators (red zone)
 - b. All power and grounds
 - c. All sensors which use DCV units in AUTO mode
 - d. Cannot use KOER Wiggle testing for switching-type signals such as injectors

APPENDIX: Methods of EEC-IV Monitor Measurements

Manual DCV

1. KOEO/KOER.
2. Select signal from PIN SELECTOR A or B.
3. Select correct ground from REFERENCE PIN Selector.
4. WIGGLE TEST will light and sound; reset WIGGLE TEST RESET button.
5. MANUAL TEST lamp should be blinking; value in DCV units.

RECORDER — ADDITIONAL MEASUREMENTS

Recorder AUX Inputs

1. KOER.
2. Monitor set-up in desired operation.
3. Device (i.e. - EFPVA) inserted into ADAPT1 or ADAPT2 of Recorder.
4. Recorder Input switch set toward Auxiliary device.
5. Recorder operation performed as normal.

Recorder DCV Wiggle Capture

1. KOER.
2. Monitor set-up for Manual DCV Wiggle.
3. Recorder CHANNELS 1-4, 6-8 selected with EEC signals.
4. Recorder CHANNEL 5 select for signal to trigger Recorder CAPTURE, switch is set to DCV (same signal is selected on Monitor on PIN SELECTOR A).
5. Optional: STO (17) could be selected so EEC processor wiggle mode would trigger capture.
6. Recorder MODE switch set to NORM, FUNCTION switch to RECORD.
7. Start vehicle, press WIGGLE TEST RESET on Monitor, set Recorder MODE switch to WIGGLE.
8. Press START RECORD button on Recorder (CAPTURE light should blink).
9. Operate vehicle until symptom occurs — the Monitor Wiggle alarm will sound and the Recorder CAPTURE function will engage. If symptom does not trigger the wiggle alarm on the Monitor, the signals can still be saved by pressing the CAPTURE button.

NOTES: SELECTOR PIN jack (red) is connected to SELECTOR PIN A/B signal at all times: AUTO, DCV and OHMS.
REFERENCE PIN jack (black) is connected to REFERENCE PIN selector signal at all times: AUTO, DCV and OHMS.

INTRODUCTION

Most threaded fasteners are covered by specifications that define required mechanical properties, such as tensile strength, yield strength, proof load and hardness. These specifications are carefully considered in initial selection of fasteners for a given application. To assure continued satisfactory vehicle performance, replacement fasteners used should be of the correct strength, as well as the correct nominal diameter, thread pitch, length, and finish.


Most original equipment fasteners (English system or Metric) are identified with markings or numbers indicating the strength of the fastener. These markings are described in the pages that follow. Attention to these markings is important in assuring that the proper replacement fasteners are used.

Further, some metric fasteners, especially nuts, are colored blue. This metric blue identification is in most cases a temporary aid for production start-up, and color will generally revert to normal black or bright after start-up.


English system and metric system fasteners are available through your Ford Parts and Service operation.

NOMENCLATURE FOR BOLTS

(ENGLISH) INCH SYSTEM Bolt, 1/2-13x1



METRIC SYSTEM Bolt M12-1.75x25




*The property class is an Arabic numeral distinguishable from the slash SAE English grade system.

**The length of all bolts is measured from the underside of the head to the end.


BOLT STRENGTH IDENTIFICATION

(ENGLISH) INCH SYSTEM



English (Inch) bolts—Identification marks correspond to bolt strength—increasing number of slashes represent increasing strength.

METRIC SYSTEM



Metric bolts—Identification class numbers correspond to bolt strength—increasing numbers represent increasing strength. Common metric fastener bolt strength property are 9.8 and 10.9 with the class identification embossed on the bolt head.

HEX NUT STRENGTH IDENTIFICATION

(ENGLISH) INCH SYSTEM

METRIC SYSTEM

Grade	Hex Nut Grade 5	Hex Nut Grade 8	Class	Hex Nut Property Class 9	Hex Nut Property Class 10
Identification			Identification		
	3 Dots	6 Dots		Arabic 9	Arabic 10
Increasing dots represent increasing strength.			May also have blue finish or paint daub on hex flat. Increasing numbers represent increasing strength.		

OTHER TYPES OF PARTS

Metric identification schemes vary by type of part, most often a variation of that used of bolts and nuts. Note that many types of English and metric fasteners carry no special identification if they are otherwise unique.

—Stamped U-Nuts

—Tapping, thread forming and certain other case hardened screws

CLASS 10.9 CLASS 9.8 CLASS 8.8

—Studs, Large studs may carry the property class number. Smaller studs use a geometric code on the end.

ENGLISH METRIC CONVERSION

Description	Multiply	By	For Metric Equivalent
ACCELERATION	Foot/sec ²	0.304 8	metre/sec ² (m/s ²)
	Inch/sec ²	0.025 4	metre/sec ²
TORQUE	Pound-inch	0.112 98	newton-metres (N·m)
	Pound-foot	1.355 8	newton-metres
POWER	horsepower	0.746	kilowatts (kw)
PRESSURE or STRESS	inches of water	0.2488	kilopascals (kPa)
	pounds/sq. in.	6.895	kilopascals (kPa)
	pounds/sq. in.	14.5	bar
ENERGY or WORK	BTU	1 055.	joules (J)
	foot-pound	1.355 8	joules (J)
	kilowatt-hour	3 600 000. or 3.6×10^6	joules (J = one W's)
LIGHT	foot candle	10.76	lumens/metre ² (lm/m ²)
FUEL PERFORMANCE	miles/gal	0.425 1	kilometres/litre (km/l)
	gal/mile	2.352 7	litres/kilometre (l/km)
VELOCITY	miles/hour	1.609 3	kilometres/hr. (km/h)
LENGTH	inch	25.4	millimetres (mm)
	foot	0.304 8	metres (m)
	yard	0.914 4	metres (m)
	mile	1.609	kilometres (km)
AREA	inch ²	645.2	millimetres ² (mm ²)
		6.45	centimetres ² (cm ²)
	foot ²	0.092 9	metres ² (m ²)
	yard ²	0.836 1	metres ²
VOLUME	inch ³	16 387.	mm ³
	inch ³	16.387	cm ³
	quart	0.016 4	litres (l)
	quart	0.946 4	litres
	gallon	3.785 4	litres
	yard ³	0.764 6	metres ³ (m ³)
MASS	pound	0.453 6	kilograms (kg)
	ton	907.18	kilograms (kg)
	ton	0.90718	tonne
FORCE	kilogram	9.807	newtons (N)
	ounce	0.278 0	newtons
	pound	4.448	newtons
TEMPERATURE	degree fahrenheit	0.556 (°F -32)	degree Celsius (°C)

DECIMAL AND METRIC EQUIVALENTS

Fractions	Decimal Inch	Metric mm
1/64	.015625	.397
1/32	.03125	.794
3/64	.046875	1.191
1/16	.0625	1.588
5/64	.078125	1.984
3/32	.09375	2.381
7/64	.109375	2.778
1/8	.125	3.175
9/64	.140625	3.572
5/32	.15625	3.969
11/64	.171875	4.366
3/16	.1875	4.763
13/64	.203125	5.159
7/32	.21875	5.556
15/64	.234375	5.953
1/4	.250	6.35
17/64	.265625	6.747
9/32	.28125	7.144
19/64	.296875	7.54
5/16	.3125	7.938
21/64	.328125	8.334
11/32	.34375	8.731
23/64	.359375	9.128
3/8	.375	9.525
25/64	.390625	9.922
13/32	.40625	10.319
27/64	.421875	10.716
7/16	.4375	11.113
29/64	.453125	11.509
15/32	.46875	11.906
31/64	.484375	12.303
1/2	.500	12.7

Fractions	Decimal Inch	Metric mm
33/64	.515625	13.097
17/32	.53125	13.494
35/64	.546875	13.891
9/16	.5625	14.288
37/64	.578125	14.684
19/32	.59375	15.081
39/64	.609375	15.478
5/8	.625	15.875
41/64	.640625	16.272
21/32	.65625	16.669
43/64	.671875	17.066
11/16	.6875	17.463
45/64	.703125	17.859
23/32	.71875	18.256
47/64	.734375	18.653
3/4	.750	19.05
49/64	.765625	19.447
25/32	.78125	19.844
51/64	.796875	20.241
13/16	.8125	20.638
53/64	.828125	21.034
27/32	.84375	21.431
55/64	.859375	21.828
7/8	.875	22.225
57/64	.890625	22.622
29/32	.90625	23.019
59/64	.921875	23.416
15/16	.9375	23.813
61/64	.953125	24.209
31/32	.96875	24.606
63/64	.984375	25.003
1	1.00	25.4

TORQUE CONVERSION

NEWTON METRES (N·m)	POUND-FEET (LB·FT)
1	0.7376
2	1.5
3	2.2
4	3.0
5	3.7
6	4.4
7	5.2
8	5.9
9	6.6
10	7.4
15	11.1
20	14.8
25	18.4
30	22.1
35	25.8
40	29.5
50	36.9
60	44.3
70	51.6
80	59.0
90	66.4
100	73.8
110	81.1
120	88.5
130	95.9
140	103.3
150	110.6
160	118.0
170	125.4
180	132.8
190	140.1
200	147.5
225	166.0
250	184.4

POUND-FEET (LB·FT)	NEWTON METRES (N·m)
1	1.356
2	2.7
3	4.0
4	5.4
5	6.8
6	8.1
7	9.5
8	10.8
9	12.2
10	13.6
15	20.3
20	27.1
25	33.9
30	40.7
35	47.5
40	54.2
45	61.0
50	67.8
55	74.6
60	81.4
65	88.1
70	94.9
75	101.7
80	108.5
90	122.0
100	135.6
110	149.1
120	162.7
130	176.3
140	189.8
150	203.4
160	216.9
170	230.5
180	244.0

ALPHABETICAL INDEX

A

A/C & Refrigerant System — Service	36-32-1
Compressor & Magnetic Clutch	36-32-2
Condenser	36-32-2
Diagnosis & Testing	36-32-4
Evaporator	36-32-3
Manifold Gauge Set	36-32-17
Receiver/Drier	36-32-2
Refrigerant System Service	36-32-17
Service Precautions	36-32-2
Service Tools	36-32-22
System Charging	36-32-18
System Components	36-32-20
System Discharging	36-32-17
System Evacuating	36-32-17
Thermostatic Expansion Valve — TXV	36-32-3
A/C-Heater System, Manual	36-41-1
A/C Auxiliary Fan	36-41-11
A/C Hose	36-41-10
Air Distribution	36-41-3
Airflow	36-41-2
Blower Switch	36-41-1
Condenser	36-41-9
Disassembly & Assembly	36-41-12
Evaporator Assembly	36-41-10
Operation	36-41-8
Receiver Dryer	36-41-10
Removal & Installation	36-41-9
Specifications	36-41-13
Temperature Control	36-41-3
Air Cleaner & Duct Systems	24-41-1
Air Cleaner Assembly	24-41-2
Removal & Installation	24-41-1
Testing	24-41-1
Alternator — Integral Regulator — External	
Fan Type	31-17-1
Adjustments	31-17-2
Cleaning & Inspection	31-17-11
Disassembly & Assembly	31-17-3
On-Bench Testing	31-17-12
Removal & Installation	31-17-2
Service Tools	31-17-16
Specifications	31-17-16
Testing	31-17-12
Voltage Regulator	31-17-2
Antennas	35-10-1
Diagnosis & Testing	35-10-1
Removal & Installation	35-10-2

Ash Receptacles & Cigar Lighter	35-40-1
Diagnosis & Testing	35-40-1
Removal & Installation	35-40-3

B

Batteries	31-02-1
Battery Capacity Test	31-02-3
Battery Charging	31-02-3
Battery Voltage Check	31-02-1
Cleaning	31-02-6
Maintenance	31-02-5
Removal & Installation	31-02-4
Service	31-02-4
Service Tools	31-02-6
Testing	31-02-1
Tools	31-02-4
Body	47-02-1
Alignment	47-02-8
Body & Sheet Metal	47-02-1
Body Panels	47-02-8
Bumper Assembly, Front	47-02-2
Bumper Assembly, Rear	47-02-3
Bumper Covers	47-02-11
Engine Compartment Underbody Panels	47-02-7
Exterior Parts, Flexible — Refinishing	47-02-15
Fender	47-02-6
Inner Splash Shield, Front Fender	47-02-5
Removal & Installation	47-02-2
Repair	47-02-11
Specifications	47-02-15
Splash Shield, A-Pillar	47-02-6
Stone Guard, Front	47-02-8
Support & Bracket, Front Center	47-02-8
Body Shell, Exterior Trim, Frame & Underbody — Service	47-01-1
Adjustments	47-01-2
Appearance Protection	47-01-9
Body Alignment, Unitized	47-01-2
Body Dimensions	47-01-3
Body Maintenance	47-01-9
Body Misalignment Check	47-01-2
Body Sealer Types	47-01-2
Body Side Protection Mouldings	47-01-7
Cleaning & Inspection	47-01-7
Diagnosis & Testing	47-01-2
Dust & Water Leaks	47-01-2
Floorpan Plugs & Grommets	47-01-7
Rattle Elimination	47-01-8
Removal & Installation	47-01-7

ALPHABETICAL INDEX

Service Tools	47-01-10
Trim	47-01-8
Underbody Misalignment Check	47-01-2

Brake Booster, Vacuum — Dash Mounted	12-50-1
Adjustments	12-50-2
Inspection	12-50-3
Master Cylinder Push Rod Adjustment	12-50-2
Power Booster	12-50-3
Push Rod Length	12-50-2
Removal & Installation	12-50-3
Service Tools	12-50-3
Vacuum Hose & Check Valve	12-50-3

Brakes, Disc — Single Piston, Sliding	
Caliper — Front	12-20-1
Brake Pads	12-20-3
Brake Rotor Refinishing	12-20-11
Caliper	12-20-5
Disassembly & Assembly	12-20-8
Overhaul	12-20-10
Removal & Installation	12-20-3
Rotor	12-20-7
Service Precautions	12-20-3
Service Tools	12-20-12
Specifications	12-20-12

Brakes, Disc — Single Piston, Sliding	
Caliper — Rear	12-25-1
Brake Pads	12-25-5
Brakes, Parking	12-25-3
Caliper	12-25-8
Disassembly & Assembly	12-25-11
Removal & Installation	12-25-5
Rotor	12-25-9
Service Tools	12-25-13
Specifications	12-25-13

Brakes, Hydraulic — Service	12-01-1
Adjustments	12-01-30
Brake Booster Functional Test	12-01-11
Brake Pedal	12-01-19
Brake Pedal Height	12-01-14
Brake Pedal Travel Measurement	12-01-14
Brake Shudder	12-01-15
Brake System — Dual	12-01-2
Brake Tube Replacement	12-01-31
Caliper Hose	12-01-21
Diagnosis & Testing	12-01-6
Disassembly & Assembly	12-01-22
Disc Brakes, Front	12-01-4
Disc Brakes, Rear	12-01-4
Hydraulic System	12-01-6
Hydraulic System Bleeding	12-01-30

Inspection	12-01-4
Master Cylinder	12-01-18
Parking Brake	12-01-5
Removal & Installation	12-01-18
Road Test	12-01-3
Service Tools	12-01-32
Specification	12-01-32
System Priming	12-01-31

C

Carpets	45-26-1
Removal & Installation	45-26-1
Charge Indicator	33-32-1
Diagnosis & Testing	33-32-1
Removal & Installation	33-32-3
Voltmeter	33-32-3

Charging System — Service	31-01-1
Diagnosis	31-01-1
Specifications	31-01-8
Testing	31-01-3

Clock	33-15-1
Removal & Installation	33-15-1

Clutch	16-02-1
Adjustments	16-02-3
Clutch Cable	16-02-5
Clutch Cover	16-02-11
Clutch Disc	16-02-11
Clutch Pedal	16-02-6
Clutch Pedal Height	16-02-3
Clutch Pedal Switch	16-02-5
Clutch Pressure Plate, Disc & Flywheel	16-02-9
Clutch Release Bearing	16-02-11
Flywheel	16-02-12
Hydraulic Clutch Bleeding	16-02-5
Hydraulic Clutch Master Cylinder	16-02-9
Hydraulic Clutch Reservoir Fluid Level	16-02-5
Hydraulic Clutch Slave Cylinder	16-02-9
Pedal Free Play	16-02-4
Removal & Installation	16-02-5
Service Tools	16-02-15
Specifications	16-02-15

Clutch and Manual Transaxle — Diagnosis	16-01-1
Clutch & Clutch Pedal	16-01-2
Diagnosis	16-01-2
Gear Noise	16-01-6
Oil Leakage	16-01-6
Transaxle	16-01-4

ALPHABETICAL INDEX

Compressor & Clutch	36-39-1
Clutch Pulley Bearing	36-39-7
Compressor	36-39-2
Maintenance	36-39-1
Pressure Plate, Pulley & Field Coil	36-39-2
Refrigerant Oil Addition	36-39-1
Removal & Installation	36-39-2
Service Tools	36-39-8

Console, Floor	45-31-1
Console, Front	45-31-2
Console, Rear	45-31-1
Removal & Installation	45-31-1
Shifter Boot	45-31-4

Convertible	47-07-1
Adjustments	47-07-2
Convertible Top Assembly	47-07-3
Convertible Top Material	47-07-4
Convertible Top Retainer	47-07-4
Convertible Top-to-Windshield Adjustment	47-07-3
Door Glass Fit	47-07-3
Latch Effort	47-07-2
Maintenance	47-07-1
Moulding, Storage Cover-to-Convertible Top	47-07-10
Plastic Window, Rear	47-07-2
Removal & Installation	47-07-3
Specifications	47-07-17
Storage Compartment Lock Set & Actuator	47-07-13
Storage Cover	47-07-15
Storage Cover Bumpers	47-07-15
Storage Cover Hinge	47-07-17
Storage Cover Latch Cables	47-07-13
Storage Cover Pivot Caps	47-07-12
Storage Cover Strikers	47-07-14
Storage Cover Support	47-07-16
Storage Cover Trim	47-07-15
Storage Top Latch	47-07-13
Weatherstrip, Convertible Top-to-Windshield	47-07-10
Weatherstrip, Rear Seat-to-Storage Cover	47-07-11
Weatherstrip, Storage Cover-to-Body	47-07-11
Weatherstrips, Convertible Top Side	47-07-10
Window, Rear	47-07-4

Cooling System — Service	27-01-1
Coolant Condition Check	27-01-6
Coolant Draining & Replacement	27-01-7
Cooling System Flush Procedure	27-01-7
Cooling System Pressure Test	27-01-5
Diagnosis & Testing	27-01-2
Pressure Cap Testing	27-01-4
Service Tools	27-01-8
Thermostat Testing	27-01-6

D

Door — Hinge, Latch, Manual Lock and

Weatherstrip	44-06-1
Adjustments	44-06-2
Door Alignment	44-06-2
Door, Bumper	44-06-7
Door Bumper Guide	44-06-8
Door Check Assembly	44-06-7
Door Inspection	44-06-2
Door Latch	44-06-5
Door Latch Release Lever	44-06-5
Door Lock Cylinder	44-06-6
Door, Striker	44-06-3
Front Door & Hinges	44-06-4
Outside Door Handle	44-06-6
Removal & Installation	44-06-4
Specifications	44-06-9
Weatherstrip	44-06-8

Door Lock, Power	44-16-1
Diagnosis & Testing	44-16-2
Door Lock Actuator	44-16-5
Door Lock Control Switch	44-16-6
Removal & Installation	44-16-5
Specifications	44-16-6

Drive Belts, Accessory — Service	27-02-1
Adjustments	27-02-1
Alternator/Water Pump Drive Belt Tension	27-02-1
Drive Belt, Alternator	27-02-3
Drive Belt Power Steering & A/C	27-02-4
Power Steering & A/C Drive Belt Tension	27-02-2
Removal & Installation	27-02-3

E

Engine Coolant Temperature Indicating System ..	33-25-1
Diagnosis & Testing	33-25-1
Removal & Installation	33-25-5
Temperature Sending Unit	33-25-5

Engine, 1.6L	21-10-1
Camshaft	21-10-14
Camshaft Seals	21-10-22
Connecting Rod	21-10-39
Core Plugs	21-10-23
Crankshaft	21-10-39
Crankshaft End Play	21-10-40
Crankshaft, Main Bearings & Connecting Rod Bearings	21-10-16

ALPHABETICAL INDEX

Crankshaft Oil Clearance	21-10-40	Diagnosis & Testing	27-10-2
Crankshaft Oil Seal, Front	21-10-23	Removal & Installation	27-10-9
Crankshaft Oil Seal, Rear	21-10-23	Specifications	27-10-10
Cylinder Block	21-10-34	Fuel Filters	24-51-1
Cylinder Block Flatness	21-10-35	In-Line Filter	24-51-1
Cylinder Bores	21-10-36	In-Tank Filter	24-51-1
Cylinder Head	21-10-42	Removal & Installation	24-51-1
Disassembly & Assembly	21-10-24	Fuel Injection, Electronic	24-05-1
Engine Mount, Front	21-10-9	Adjustments	24-05-13
Engine Mount, Rear	21-10-9	Airflow	24-05-8
Engine Mounts, RH	21-10-9	Air Induction System	24-05-6
Exhaust Manifold	21-10-18	BAC Valve	24-05-16
HLA	21-10-46	BP Sensor	24-05-16
Intake Manifold	21-10-17	Bypass Air Control Valve	24-05-9
Oil Pan	21-10-19	Diagnosis & Testing	24-05-13
Oil Pump	21-10-20	Electronic Control Assembly	24-05-14
Piston & Connecting Rod Assembly	21-10-21	Electronic Engine Control	24-05-10
Pistons, Piston Rings & Piston Pins	21-10-37	Engine Coolant Temperature Sensor	24-05-15
Removal & Installation	21-10-2	Fuel Injectors	24-05-15
Service Procedures	21-10-34	Fuel System	24-05-4
Service Tools	21-10-49	Idle Speed	24-05-13
Specifications	21-10-47	Oxygen Sensor	24-05-16
Subassemblies	21-10-32	Removal & Installation	24-05-13
Timing Belt	21-10-12	Service Tools	24-05-17
Valve Stem Seals	21-10-19	Specifications	24-05-17
Engine, Gasoline — Service	21-01-1	Throttle Body	24-05-13
Camshaft Lobe Lift	21-01-4	Throttle Position Sensor	24-05-15
Compression Test	21-01-3	Turbo Boost Gauge	24-05-16
Diagnosis & Testing	21-01-2	Vane Air Flow Meter	24-05-14
Emissions Calibration Label	21-01-2	Fuel Level Indicating System	33-20-1
Engine Identification	21-01-2	Diagnosis & Testing	33-20-1
Engine Oil Leaks	21-01-2	Fuel Gauge	33-20-3
Exhaust Emission Control System	21-01-2	Fuel Tank Sending Unit	33-20-3
Positive Closed-Type Crankcase Ventilation System	21-01-2	Removal & Installation	33-20-3
Service Tools	21-01-5	Fuel Pump — Electric	24-35-1
Valve Train Analysis	21-01-4	Control Circuit	24-35-2
Exhaust System	26-01-1	Fuel Pump Relay	24-35-4
Diagnosis	26-01-1	Pressure Regulator	24-35-3
Exhaust Leakage or Noise	26-01-1	Removal & Installation	24-35-3
Removal & Installation	26-01-4	Fuel System — Service	24-01-1
Restricted Exhaust System	26-01-3	Air Cleaner	24-01-2
		Cleaning & Inspection	24-01-2
		Fuel Injection, Electronic	24-01-2
		Testing & Adjustments	24-01-2
		Fuel Tanks and Lines	24-50-1
		Fuel Filler Door	24-50-3
		Fuel Filler Neck	24-50-5
		Fuel System Pressure Relief	24-50-2
		Fuel Tank	24-50-4
		Removal & Installation	24-50-2

F

Fan, Electro-Drive Cooling	27-10-1
Coolant Temperature Switch	27-10-9
Cooling Fan	27-10-9
Cooling Fan Motor	27-10-9
Cooling Fan Relay	27-10-10

ALPHABETICAL INDEX

Fuses & Circuit Breakers	34-50-1
Fuse Link	34-50-4
Fuse Link — Charging System	34-50-3
Fuse Panel, Interior	34-50-3
Main Fuse Box	34-50-3
Removal & Installation	34-50-3

G

Glass, Stationary — Windshield	43-02-1
Mouldings, Front Window	43-02-1
Removal & Installation	42-02-1
Windshield	43-02-4

H

Halfshafts & CV Joints — Front-Wheel Drive	15-22-1
Diagnosis	15-22-5
Disassembly & Assembly	15-22-11
Halfshaft Handling	15-22-4
Jointshaft	15-22-11
Removal & Installation	15-22-8
Rzeppa CV Joint	15-22-13
Service Tools	15-22-22
Specifications	15-22-22
Tripot Joint	15-22-19

Hardtop, Removable	47-10-1
Exterior Mouldings, Side & Rear	47-10-4
Hardtop Front Attachment Bracket	47-10-5
Hardtop Side & Rear Windows	47-10-6
Hardtop-to-Vehicle Weatherstrip	47-10-4
Headlining	47-10-6
Mouldings, Roof	47-10-4
Removal & Installations	47-10-1
Side/Rear Attachments	47-10-5
Side Window Opening Weatherstrip	47-10-4
Trim Panel, Rear	47-10-3
Trim Panels, Interior Side	47-10-3
Window Retainer Moulding, Side	47-10-3
Wiring Harness	47-10-5

Headlamp System	32-02-1
Adjustments	32-02-15
Diagnosis & Testing	32-02-6
Fog Lamp	32-02-18
Fog Lamp Switch	32-02-18
Headlamp Aim	32-02-15
Headlamp Assembly	32-02-16
Headlamp Motor	32-02-16
Headlamp Motor Switch	32-02-18
Headlamp Switch	32-02-17
High Beam/Flash-to-Pass Switch	32-02-18

High Beam Indicator Lamp Bulb	32-02-18
Linkage	32-02-17
Removal & Installation	32-02-15

Heater & Power Ventilation System	36-10-1
Adjustments	36-10-15
Air Distribution	36-10-2
Air Door Control Cable	36-10-16
Airflow	36-10-1
Air Inlet Duct	36-10-26
Blower Case Assembly	36-10-19
Blower Motor	36-10-18
Blower Motor Resistor	36-10-18
Blower Switch	36-10-17
Control Cables	36-10-17
Defroster Ducts	36-10-24
Defroster Tubes & Side Demister Tubes	36-10-25
Diagnosis & Testing	36-10-5
Function Selector Cable	36-10-15
Function Selector Rod	36-10-15
Heat Ducts, Rear Seat	36-10-25
Heater Case	36-10-20
Heater Control Panel	36-10-16
Heater Core	36-10-22
Heater Hoses	36-10-23
Heater Tube, LH	36-10-27
Instrument Panel Ducts	36-10-26
Register, LH Side & Center	36-10-24
Register, RH Side	36-10-24
Removal & Installation	36-10-16
Temperature Control	36-10-2
Temperature Control Cable	36-10-15

Heating System — Service	36-01-1
Bench Test	36-01-3
Diagnosis	36-01-4
Heater Core	36-01-2
Heater Core Leak Test	36-01-3
Heating Systems & Control Doors	36-01-2
Pressure Test	36-01-3
Service Tools	36-01-5
Testing	36-01-2

Hoisting, Jacking & Towing	10-04-1
Hoisting & Jacking	10-04-1
T-Hooks, Front	10-04-5
T-Hooks, Rear	10-04-5
Towing	10-04-3
Towing Procedures	10-04-4
Towing Slings	10-04-3

Hood, Hinge & Latch	44-08-1
Adjustments	44-08-2
Hood	44-08-8
Hood Alignment	44-08-2
Hood Bumpers	44-08-3
Hood Hinge	44-08-5
Hood Latch	44-08-5

ALPHABETICAL INDEX

Hood Release Cable	44-08-6
Hood Safety Latch	44-08-6
Hood Seals	44-08-5
Hood Support Rod	44-08-7
Hood Weatherstrip	44-08-4
Latch Adjustments	44-08-2
Removal & Installation	44-08-3

Horns	35-80-1
Adjustments	35-80-3
Diagnosis & Testing	35-80-1
Horn Relay	35-80-4
Horn Switch	35-80-4
Removal & Installation	35-80-3

I

Identification Codes	10-01-1
Anti-Theft Labels	10-01-2
Exterior/Interior Labels	10-01-4
Label Locations	10-01-3
Official Vehicle Identification Number	10-01-1
Replacement VIN Label	10-01-2
Vehicle Certification Label	10-01-2
Ignition Switch	31-20-1
Ignition Lock Tumbler	31-20-2
Non-Functioning Locks	31-20-3
Removal & Installation	31-20-2
Switch, Blade-Type	31-20-1
Testing	31-20-1
Ignition System Service	23-03-1
Diagnosis & Testing	23-03-2
Disassembly & Assembly	23-03-4
Distributor	23-03-4
Distributor Cap & Rotor	23-03-2
Ignition Coil	23-03-3
Operation	23-03-2
Removal & Installation	23-03-2
Secondary Ignition Wires	23-03-2
Spark Plugs	23-03-3
Instrument Cluster	33-01-1
Diagnosis & Testing	33-01-4
Disassembly & Assembly	33-01-12
Heater Control Panel Bulb	33-01-11
Instrument Cluster Bulbs	33-01-11
Panel Dimmer Switch	33-01-11
Removal & Installation	33-01-10
Speed Sensor	33-01-11

Instrument Panel & Glove Compartment	45-61-1
Instrument Cluster Bezel	45-61-1
Instrument Panel Assembly	45-61-2
Removal & Installation	45-61-1

L

Lamps, Interior	32-60-1
Diagnosis & Testing	32-60-2
Door Switch	32-60-7
Lamp/Blub Glove Compartment	32-60-8
Lamp, Dome	32-60-6
Lamps, Courtesy	32-60-7
Lens/Bulb, Cargo Lamp	32-60-9
Removal & Installation	32-60-6
Lamps — Parking, Rear and Marker	32-20-1
Combination Lamp/Bulb Replacement	32-20-7
Combination Lamp, Rear	32-20-6
Diagnosis & Testing	32-20-2
Hi-Mount Brakelamp	32-20-7
License Plate Lamp/Bulb	32-20-7
Parking Lamp/Bulb, Front	32-20-6
Removal & Installation	32-20-6
Side Marker Lamp/Bulb, Front	32-20-6
Side Marker Lamps, Rear	32-20-8
Stoplamp Switch	32-20-8
Lubrication Points and Lubricant	
Specifications	10-03-1
Lubrication	10-03-1
Specifications	10-03-3
Luggage Compartment — Door, Hinge, Latch,	
Lock and Weatherstrip	44-10-1
Adjustments	44-10-1
Alignment	44-10-1
Door	44-10-3
Door Bumpers	44-10-8
Gas Lift Cylinders	44-10-6
Glove Compartment	44-10-9
Hinge	44-10-5
Latch	44-10-5
Latch, Glove Compartment	44-10-10
Lock Cylinder	44-10-5
Lock, Glove Compartment	44-10-10
Removal & Installation	44-10-2
Spoiler	44-10-8
Striker	44-10-2
Striker, Glove Compartment	44-10-9
Weatherstrip	44-10-7

ALPHABETICAL INDEX

M

Mirrors, Exterior	42-25-1
Diagnosis & Testing	42-25-2
Mirror Assembly	42-25-7
Removal & Installation	42-25-7
Switch	42-25-7
Mirrors, Inside	42-21-1
Removal & Installation	42-21-1
Mouldings	45-16-1
Convertible Top Retainer	45-16-1
Door Scuff Plate & Side Trim	45-16-4
Hardtop Header Trim Cover	45-16-3
Removal & Installation	45-16-1
Specifications	45-16-4
Windshield Moulding, Side	45-16-2
Windshield Moulding, Upper	45-16-2

N

Noise, Vibration and Harshness	18-01-1
Diagnosis & Testing	18-01-6
Diagnostic Theory	18-01-1
Glossary	18-01-2
Non-Transaxle Noise	18-01-4
NVH Diagnosis	18-01-4
Road Test	18-01-4
Service Tools	18-01-12
Transaxle Noise	18-01-4

O

Oil Pressure Indicating System	33-34-1
Diagnosis & Testing	33-34-1
Oil Pressure Sending Unit	33-34-4
Removal & Installation	33-34-4

P

Parking Brake, Cable Actuated —	
Rear Wheels	12-70-1
Adjustment	12-70-2
Cable, Parking Brake	12-70-2

Cables, Long	12-70-4
Parking Brake Lever	12-70-3
Removal & Installation	12-70-3

R

Radiator	27-03-1
Cleaning — External & Internal	27-03-13
Leak Testing	27-03-13
Oil Cooler Transfer or Replacement	27-03-13
Radiator Core	27-03-14
Radiator Tank	27-03-5
Removal & Installation	27-03-3
Service Procedures	27-03-14
Service Tools	27-03-17
Testing	27-03-13
Thermostat	27-03-5
Water Pump	27-03-4

Restraint System — Supplemental Air Bag	41-58-1
Air Bag Clockspring	41-58-32
Air Bag Module	41-58-31
Backup Power Supply	41-58-32
Deactivating the System	41-58-29
Deployed Air Bag	41-58-28
Descriptions	41-58-1
Diagnosis & Testing	41-58-4
Diagnostic Assembly	41-58-31
Disposal Procedures	41-58-27
Live Air Bags	41-58-27
Operation	41-58-4
Parts Replacement	41-58-26
Reactivating the System	41-58-29
Removal & Installation	41-58-29
Sensor, Front Center	41-58-29
Sensor, Front, Left or Right	41-58-30
Sensor, Rear	41-58-30
Service Precautions	41-58-27
Specifications	41-58-32
Undeployed Air Bag — Faulty	41-58-28

S

Scheduled Maintenance	10-02-1
Emission Control Information Decal	10-02-1
Maintenance Schedules	10-02-3
Seat and Shoulder Safety Belts	41-50-1
Belt Webbing	41-50-5

ALPHABETICAL INDEX

Buckle Assembly, Front	41-50-2	Rear Seat Speakers	35-30-3
Cleaning	41-50-5	Removal & Installation	35-30-2
Major Service Operations	41-50-4	Speed Control System	37-01-1
Removal & Installation	41-50-2	Actuator	37-01-11
Retractor & Harness Assembly, Front	41-50-2	Actuator Cable	37-01-9
Retractor & Harness Assembly, Rear	41-50-3	Adjustments	37-01-9
Safety Belt Maintenance	41-50-4	Cable/Actuator Assembly	37-01-10
Seat Buckle, Rear	41-50-4	Clutch Pedal Height	37-01-9
Seat, Child Restraint — Tether Attachment	41-52-1	Control Module	37-01-10
Installation	41-52-1	Control Switches	37-01-9
Seats, Front	41-04-1	Diagnosis & Testing	37-01-3
Head Restraint & Cover	41-04-7	Removal & Installation	37-01-9
Lumbar Support	41-04-8	Speedometer	33-10-1
Reclining Mechanisms	41-04-7	Assembly	33-10-4
Removal & Installation	41-04-1	Diagnosis & Testing	33-10-1
Seat Back	41-04-4	Removal & Installation	33-10-3
Seat Back Cover & Cushion	41-04-5	Speedometer Cable Core	33-10-4
Seat Cover & Cushion	41-04-3	Speedometer Driven Gear	33-10-4
Seat Height Adjuster, LH Seat	41-04-9	Starter, Positive Engagement	28-02-1
Seat Height Adjustment Mechanism Control Assembly, LH Seat	41-04-9	Disassembly & Assembly	28-02-5
Specifications	41-04-10	Jump Starting	28-02-2
Seats, Rear	41-20-1	Pinion Depth Adjustment	28-02-3
Actuator Lock Set	41-20-8	Removal & Installation	28-02-5
Cable Actuator	41-20-7	Service Tools	28-02-13
Latch, Seat Back	41-20-5	Specifications	28-02-13
Latch Cable, Seat Back	41-20-6	Starter Motor No-Load Test	28-02-4
Removal & Installation	41-20-1	Testing	28-02-2
Seat Back & Cover	41-20-1	Starting System — Service	28-01-1
Seat Cushion	41-20-4	Diagnosis & Testing	28-01-2
Shift Control Linkage	17-02-1	Neutral Safety Switch	28-01-7
Adjustments	17-02-2	On-Vehicle Inspection	28-01-2
Disassembly & Assembly	17-02-7	Removal & Installation	28-01-7
Gear Selector	17-02-7	Service Tools	28-01-7
Gear Selector Assembly	17-02-5	Voltage Drop Tests	28-01-3
Removal & Installation	17-02-4	Steering Column	13-04-1
Shift Control Cable	17-02-4	Air Bag Module	13-04-2
Specifications	17-02-10	Component Fasteners	13-04-2
Sound Systems	35-01-1	Disassembly & Assembly	13-04-6
AM/FM Multiplex Radio — ESR	35-01-3	Intermediate Shaft	13-04-4
AM/FM Multiplex with Cassette Player	35-01-4	Removal & Installation	13-04-3
Cassette Tape Player	35-01-3	Specifications	13-04-10
Diagnosis & Testing	35-01-6	Steering Column Support Brackets	13-04-5
Premium Sound	35-01-2	Steering Wheel	13-04-3
Premium Sound Amplifier	35-01-18	Turn Signal Cancel Cam Service	13-04-9
Radio Reception	35-01-2	Steering Gear, Power Rack-and-Pinion	13-46-1
Removal & Installation	35-01-17	Adjustments	13-46-5
Speakers	35-30-1	Disassembly & Assembly	13-46-7
Diagnosis	35-30-1	Dust Boot	13-46-6
Door Mounted Speakers	35-30-2	Rack Yoke Preload	13-46-5
		Removal & Installation	13-46-6

ALPHABETICAL INDEX

Service Tools	13-46-17
Specifications	13-46-17
Tie Rod End	13-46-6

Steering, Power — Hoses	13-55-1
High Pressure Hose	13-55-2
Pressure/Return Tubing	13-55-3
Removal & Installation	13-55-2
Return Hose	13-55-3

Steering Pump, Power	13-51-1
Adjustments	13-51-2
Cleaning & Inspection	13-51-6
Disassembly & Assembly	13-51-4
Drive Belt Tension	13-51-2
Fluid Level Check	13-51-2
Flushing Power Steering System	13-51-6
Power Steering Pump	13-51-4
Pressure Regulator Valve	13-51-3
Pressure Switch	13-51-3
Pump Assembly	13-51-3
Removal & Installation	13-51-3
Start-Up Procedure	13-51-2
Testing	13-51-2

Steering — Service	13-01-1
Pump Flow & Pressure Tests	13-01-4
Service Tools	13-01-7
Specifications	13-01-7
Steering Wheel Free Play	13-01-5
Testing	13-01-2

Suspension, Front	14-10-1
Ball Joint	14-10-2
Control Arm	14-10-5
Disassembly & Assembly	14-10-5
Removal & Installation	14-10-2
Service Tools	14-10-6
Specifications	14-10-6
Strut & Spring	14-10-3

Suspension, Rear	14-32-1
Control Arms & Trailing Arm	14-32-7
Removal & Installation	14-32-4
Service Tools	14-32-11
Specifications	14-32-11
Spindle	14-32-6
Strut & Spring, Rear	14-32-4

Suspension — Service	14-01-1
Adjustments	14-01-6
Ball Joints	14-01-4
Camber	14-01-6
Control Arms & Stabilizers	14-01-4
Diagnosis & Testing	14-01-1

Heights	14-01-3
Specifications	14-01-9
Steering Wheel Centering	14-01-8
Steering Wheel Play	14-01-4
Struts	14-01-3
Tie Rods	14-01-4
Toe, Rear	14-01-7
Toe In, Front	14-01-6
Wheel Alignment	14-01-4

T

Tachometer	33-11-1
Diagnosis & Testing	33-11-1
Removal & Installation	33-11-5

Throttle Linkage	24-60-1
Adjustments	24-60-1
Free Play	24-60-1
Removal & Installation	24-60-2
Throttle Cable	24-60-2
Wide-Open Throttle Position	24-60-1

Transaxle, Automatic — 4EAT	17-27-1
2-3 Accumulator	17-27-80
3-4 Accumulator	17-27-77
Adjustments	17-27-29
Bearing Housing	17-27-94
Bearing Locator	17-27-96
Bearing Preload & Shim Selection	17-27-31
Bearing/Stator Support	17-27-95
Cleaning & Inspection	17-27-97
Clutch Assemblies	17-27-68
Diagnosis & Testing	17-27-4
Differential	17-27-90
Disassembly & Assembly	17-27-42
Idler Gear	17-27-92
Kickdown Cable	17-27-29
Major Service Operations	17-27-29
Oil Cooler	17-27-31
Oil Pump	17-27-63
One-Way Clutch & Planetary Carrier Assembly	17-27-76
Output Gear	17-27-91
Removal & Installation	17-27-36
Service Tools	17-27-102
Small Sun Gear & One-Way Clutch	17-27-74
Specifications	17-27-100
Subassemblies	17-27-63
Torque Converter	17-27-98
Transaxle Fluid Level Check	17-27-29
Valve Body	17-27-80

ALPHABETICAL INDEX

Transaxle, Automatic — Service 17-01-1
Description 17-01-1

Transaxle, Manual — 5-Speed — Non-Turbo

Engine 16-37-1
Cleaning & Inspection 16-37-43
Clutch Housing 16-37-25
Differential 16-37-37
Disassembly & Assembly 16-37-17
Gearshift Linkage 16-37-13
General Service Procedures 16-37-15
Input Shaft 16-37-43
Main Shaft 16-37-44
Main Shift Rail 16-37-40
Operation 16-37-2
Removal & Installation 16-37-5
Service Tools 16-37-46
Shift Linkage 16-37-5
Specifications 16-37-46
Subassemblies 16-37-24
Transaxle Fluid Level Check 16-37-15
Transaxle Housing 16-37-30
Transaxle Oil Seal 16-37-10

Transaxle, Manual — 5-Speed — Turbo Engine .. 16-38-1

Differential 16-38-39
Differential Shim Selection 16-38-63
Disassembly & Assembly 16-38-18
Gear & Shaft 16-38-35
Gearshift Linkage 16-38-7
Input Gear Shaft Shim Selection 16-38-61
Input Shaft Bearing 16-38-57
Main Shaft Shim Selection 16-38-58
Operation 16-38-3
Removal & Installation 16-38-7
Service Procedures 16-38-17
Service Tools 16-38-66
Shift Linkage 16-38-6
Specifications 16-38-65
Subassemblies 16-38-35
Transaxle Fluid Level Check 16-38-17
Transaxle Oil Seal 16-38-9

Trim Panels, Interior 45-03-1

Convertible Top Storage Compartment 45-03-13
Cowl Side Trim Panel 45-03-8
Door Trim Panels 45-03-1
Floor Panels, Luggage Compartment 45-03-15
Luggage Compartment Rear Trim Panels 45-03-14
Luggage Compartment Side Trim Panels 45-03-14
Rear Quarter Trim Panels 45-03-8
Removal & Installation 45-03-1
Watershield 45-03-7

Turbo Boost Indicating System 33-36-01
Boost Gauge 33-36-3
Boost Gauge Sensor 33-36-3
Diagnosis & Testing 33-36-1
Removal & Installation 33-36-3

Turbocharger 24-45-1
Air-Fuel/Exhaust Gas Flow 24-45-2
Bearing Clearance Check 24-45-9
Boost Control, Automatic 24-45-2
Coolant Return Hose 24-45-7
Coolant Supply Hose & Fitting 24-45-7
Diagnosis & Testing 24-45-9
Intercooler 24-45-7
Intercooler Hoses 24-45-8
Lubrication 24-45-1
Oil Return Hose 24-45-7
Oil Supply Line 24-45-6
Operation 24-45-2
Overboost Pressure Switch 24-45-8
Removal & Installation 24-45-2
Specifications 24-45-12

Turn Signal and Hazard Flasher 32-40-1
Diagnosis & Testing 32-40-2
Hazard Flasher Unit 32-40-7
Removal & Installation 32-40-6
Switch Assembly 32-40-6
Turn Signal Flasher Unit 32-40-7
Wiper Switch & Turn Signal/
High Beam Lever 32-40-6

W

Warning Indicator 33-45-1
Brake Indicator 33-45-1
Diagnosis & Testing 33-45-3
Engine Warning Lamp 33-45-1
High Beam Indicator 33-45-2
Instrument Panel Lamps 33-45-1
Parking Brake Switch 33-45-10
Removal & Installation 33-45-10
Safety Belt Indicator 33-45-1
Safety Belt Switch 33-45-11
Warning/Indicator Lamp Bulbs 33-45-10

Wheel Hubs and Bearings — Front 11-10-1
Bearing, Front 11-10-2
Brake Rotor/Wheel Hub 11-10-9
Diagnosis 11-10-2
Disassembly & Assembly 11-10-9
Removal & Installation 11-10-3

ALPHABETICAL INDEX

Service Tools	11-10-15	Removal & Installation	42-08-6
Specifications	11-10-15	Window Channel, Rear	42-08-11
Steering Knuckle/Bearings	11-10-13	Window Channels	42-08-6
Wheel Hub/Steering Knuckle Assembly	11-10-3	Window Glass	42-08-7
Wheel Hubs & Bearings — Rear	11-15-1	Window Guide	42-08-7
Adjustments	11-15-6	Window Stop	42-08-6
Bearing Preload	11-15-6	Windshield Washers	35-70-1
Bearing Races	11-15-9	Diagnosis & Testing	35-70-2
Brake Rotor/Bearing Hub Assembly	11-15-7	Nozzles & Hose	35-70-4
Grease Seal/Bearings	11-15-8	Pump	35-70-4
Inspection	11-15-2	Removal & Installation	35-70-4
Removal & Installation	11-15-7	Reservoir & Washer Pump	35-70-4
Specifications	11-15-9	Washer Switch	35-70-5
Wheels and Tires — Service	11-01-1	Windshield Wipers	35-60-1
Diagnosis	11-01-5	Adjustments	35-60-8
Maintenance	11-01-2	Diagnosis & Testing	35-60-3
Road Test	11-01-6	Linkage	35-60-10
Service	11-01-10	Removal & Installation	35-60-8
Service Tools	11-01-14	Specifications	35-60-10
Specifications	11-01-13	Windshield Wiper Arm Position	35-60-8
Tire and Wheel Balance	11-01-11	Wiper Arm	35-60-9
Tire Inflation	11-01-3	Wiper Blade	35-60-8
Tire Lead	11-01-9	Wiper Motor	35-60-9
Vibration & Roughness	11-01-6	Wiper Switch & Lever	35-60-10
Wheel Lug Nuts	11-01-2	Wiring Harness — Connectors	34-01-1
Wheel/Tire Runout	11-01-9	Connectors	34-01-1
Window Glass & Mechanisms — Service	42-01-1	Removal & Installation	34-01-1
Lubrication	42-01-1	Wire Ends	34-01-2
Window, Rear — Defroster	36-86-1	Wiring Harnesses	34-26-1
Bus Bar Terminal Repair	36-86-7	Dash Panel	34-26-5
Diagnosis & Testing	36-86-2	Door	34-26-6
Major Service Operations	36-86-6	Engine Compartment	34-26-3
ON/OFF Switch	36-86-7	Floor	34-26-7
Removal & Installation	36-86-7	Ground Cable	34-26-2
Windows, Power	42-08-1	Hardtop	34-26-6
Adjustments	42-08-6	Instrument Panel	34-26-6
Diagnosis & Testing	42-08-2	Lamps, Rear	34-26-9
Door Quarter Window	42-08-11	Luggage Compartment Lid	34-26-9
Door Window Switch	42-08-6	Quarter Panel	34-26-8
Motor — Regulator Assembly	42-08-9	Removal & Installation	34-26-1
		Starter & Alternator Cables	34-26-3

We Want To Hear From You!

Do you have any suggestions for improving this publication?

FOR EXAMPLE...

- **Did you find any errors?**

If yes; Manual _____ **Volume** _____ **Page** _____

- **Were any subjects not covered?**

If yes; Please describe. _____

- **Were any sections confusing or hard to understand?**

If yes; Manual _____ **Volume** _____ **Page** _____

Please comment: _____

- **Could you quickly find what you need? Yes** _____ **No** _____

Suggestions: _____

- **Tell us who you are:**

Name _____

Address _____

Position _____ **Company** _____

It is most helpful if you would enclose a copy of each page, marked with your suggestions.

DO NOT STAPLE — USE TRANSPARENT TAPE



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 400 DEARBORN, MICH.

POSTAGE WILL BE PAID BY ADDRESSEE

Ford Parts and Service Division
Advanced Service Engineering
Fairlane Technical Center
P.O. Box 1902
Dearborn, Michigan 48121

