

SECTION A

Table Of Contents

Contents

Table of Contents	A
Vehicle/Engine Application Chart	B
How to Use This Manual	C
<u>Part I: General Information</u>	
Emission Control Identification/Application	1
Diagnostic Routines	2
Emission System Description, Operation and Component Location	3
Engine Supplement — Passenger Car	4
Glossary	5
<u>Part II: Mechanical Systems</u>	
Catalyst and Exhaust Systems	6
Exhaust Gas Recirculation (EGR) (Not Equipped)	7
Evaporative Emission (EVAP) Systems	8
By-Pass Air (BPA) Control System	9
Inlet Air Control (IAC) System	10
Positive Crankcase Ventilation (PCV) Systems	11
Turbocharger Systems	12
Fuel Delivery System	13
<u>Part III: Electronic Systems</u>	
Ignition Systems and Timing Procedures	14
EEC and 4EAT — Quick Test — All Engines	15
EEC and 4EAT — Pinpoint Tests — All Vehicles	16
EEC-IV Monitor Intermittent Fault Diagnosis	17

